



Matrix 424 832 832+



LCD Programming Manual Software Version 5



RINS916-7



EN50131-1
Security Grade 2
Environmental Class 2

Pyronix Installers Club (PI Club)

Installer Support

The PI Club has been developed with the focus on what you the installer would like to see from one of the world's leading manufacturers of security equipment.

The philosophy behind the association is that you will receive tangible benefits, which are applicable to both the work and home environment.

Dedicated Website

You will have access to a dedicated PI Club section of the Pyronix website which is packed full of features that will keep you updated on Pyronix and industry news.

To Join the PI Club please register at www.pyronix.com, or for further information please contact our marketing department at marketing@pyronix.com.

As a new member of the PI Club a technical help free phone number will be issued to you.



CONTENTS

1. ENGINEER MENU SYSTEM.....	4
1.1 Entering Engineers Mode	4
1.2 Exiting Engineers Mode.....	4
1.3 Entering Engineer Menu.....	4
1.4 Exiting Engineer Menu	4
1.5 Testing Partitions.....	4
1.6 Navigating the Menu.....	4
1.6.1 Menu Sections.....	4
1.7 Initial Power up	4
1.8 Menu Structure	4
2. ACCESSING USER FUNCTIONS.....	8
3. CHANGE ENGINEER CODE (FUNCTION 125)	9
4. SYSTEM OPTIONS	10
4.1 System Options 1 (Function 200).....	10
4.2 System Options 2 (Function 201).....	11
4.3 System Options 3 (Function 202).....	12
5. ZONES.....	13
5.1 Zone Connections (Function 250)	13
5.2 Zone Names on LCD Keypad (Function 252)	13
5.3 Zone Type – Arm Mode A (Function 261)	15
5.4 Zone Type – Arm Mode B (Function 262)	15
5.5 Zone Type – Arm Mode C (Function 263).....	15
5.6 Zone Type – Arm Mode D (Function 264).....	15
5.7 Zone Attributes – Arm Mode A (Function 271).....	16
5.8 Zone Attributes – Arm Mode B (Function 272).....	16
5.9 Zone Attributes – Arm Mode C (Function 273).....	16
5.10 Zone Attributes – Arm Mode D (Function 274).....	16
5.11 Zone Partition (Function 280).....	17
5.12 Copy Arm A to B,C & D (Function 290).....	17
6. USERS.....	18
6.1 User Code Partition (Function 300).....	18
6.2 User Code Attributes (Function 301).....	19
6.3 Temporary Code (Function 302)	19
7. KEYPADS/PROXIMITY READERS	20
7.1 ICON Partition Allocation (Function 350)	20
7.2 ICON Public/Private (Function 351)	20
7.3 LCD Partition Allocation (Function 352)	21
7.4 LCD Public/Private (Function 353)	21
7.5 Change Label Messages (Function 354)	22
7.6 Assign Disarmed Labels (Function 355)	23
7.7 Assign Armed Labels (Function 356)	23
7.8 LCD Contrast (Function 357).....	23
7.9 Proximity Reader Partition Allocation (Function 358).....	23
7.10 Proximity Reader Public/Private (Function 359).....	24
7.11 LCD Keypad Language (Function 360).....	24
8. FAULTS.....	25
8.1 System Fault Partition (Function 380)	25
8.2 Bell/Tamper Fault Partition (Function 381).....	25
9. PARTITION OPTIONS	26
9.1 Partition Options 1 (Function 400).....	26
9.2 Partition Options 2 (Function 401).....	27
10. ARM OPTIONS.....	28
10.1 Exit Terminator – Arm Mode A (Function 450).....	28
10.2 Exit Terminator – Arm Mode B (Function 451).....	28
10.3 Exit Terminator – Arm Mode C (Function 452).....	28
10.4 Exit Terminator – Arm Mode D (Function 453).....	28
10.5 Home & Away Allocation (Function 454).....	29

10.6 Partition Dependency (Function 455)	30
10.7 Keypad Arm Mode Allocation (Function 456)	31
10.8 Number of Rearms (Function 457)	31
11. SYSTEM TIMERS	32
11.1 Bell Time (Function 500).....	32
11.2 Bell Time Delay (Function 501)	32
11.3 Entry Time (Function 502)	32
11.4 Exit Time (Function 503).....	33
11.5 Final Exit Delay (Function 504).....	33
11.6 Auto Arm Commence Time (Function 505)	33
11.7 Inactivity Auto Arm (Function 506).....	34
11.8 AC Fail Warning Delay (Function 507)	34
11.9 Telephone Line Fail Warning Delay (Function 508)	34
11.10 Seconds in Last Minute of Day (Function 509).....	34
12. OUTPUTS	35
12.1 Zone to Follow in Partition (Function 551).....	35
12.2 PGM Type (Function 555)	35
12.2.1 PGM Types.....	36
12.3 PGM Options (Function 556).....	37
13. COMMUNICATIONS	38
13.1 Account Codes & Partitions Allocation (Function 600).....	38
13.2 Up/Downloading Access Code (Function 601).....	38
13.3 Digital Communicator Options 1 (Function 602).....	39
13.4 Test Dial Time (Function 603)	39
13.5 Test Dial Interval (Function 604).....	40
13.6 Telephone Number 1 Allocation (Function 605).....	40
13.7 Telephone Number 2 Allocation (Function 606).....	40
13.8 Telephone Number 3 Allocation (Function 607).....	40
13.9 Test Dial Sequence (Function 608)	41
13.10 Anti-Code Algorithm (Function 609)	41
13.11 Digital Communicator Options 2 (Function 610).....	41
14. REPORTING	42
14.1 Telephone Number Only (Function 651)	42
14.2 Telephone Format Only (Function 652).....	43
14.3 BSIA Format Channel Map (Function 655)	43
15. SEND OPTIONS	44
15.1 Disarmed Mode Events Send Options (Function 700).....	44
15.2 Arm Mode A Events Send Options (Function 701).....	45
15.3 Arm Mode B Events Send Options (Function 702).....	45
15.4 Arm Mode C Events Send Options (Function 703)	45
15.5 Arm Mode D Events Send Options (Function 704)	45
15.6 Restoral Events Send Options (Function 705)	46
15.7 Allocating Telephone Numbers to Alarm Types (Function 706).....	47
15.8 MX-VOICE Module Support (Function 707)	48
15.9 Number of Voice Dials (Function 709).....	48
16. MAINTENANCE	49
16.1 Viewing Event Log Memory (Function 113).....	49
16.1.1 Event Log Interpretation Table	50
16.2 Engineer Code NVM Reset (Function 751)	55
16.3 Programmable Outputs Test (Function 752)	55
16.4 Walk Test (Function 753).....	55
16.5 Scan for Devices on the Bus (Function 754)	55
16.6 Local Up/Downloading – RS232 (Function 755)	55
16.7 Battery Charger Test (Function 756)	56
16.8 Panel Software Version Number (Function 757)	57
17. DD243	58
17.1 DD243 Options 1 (Function 800)	58
17.2 DD243 Zone Map (Function 802)	58
17.3 DD243 Partition Confirmation Times (Function 804)	59

18. WIRELESS	60
18.1 Program Key fob (Function 900)	60
18.2 Key Fob Actions	61
18.3 Supervision Time (Function 901).....	61
19. CONTACT ID EVENT CODES	62
20. ENGINEER QUICK REFERENCE	64
20.1 Entering / Exiting Engineer Mode.....	64
20.2 Programming Functions	64
20.3 Engineer Functions.....	66

1. ENGINEER MENU SYSTEM

1.1 Entering Engineers Mode

- Enter Engineer mode by pressing **[] [] X X X X (X X)** (default engineer code - 9999).
- Press **[]**. 'Engineers Mode' will be displayed.

Note: *Engineer mode can only be entered if all partitions are disarmed.*

1.2 Exiting Engineers Mode

- Press **[]** then **[0]**. If any tampers are active, then these will be displayed on the keypad.
- Press **[]** then **[0]** to exit engineers mode.

1.3 Entering Engineer Menu

NOTE: *The Engineer Menu is currently only available on UK LCD keypads.*

- In Engineers Mode, Press the **[]** key.

1.4 Exiting Engineer Menu

- Press the **[]** key. Note: You must not be in an active function.

1.5 Testing Partitions

A test facility for all partitions is available in Engineers Mode. To enter this function, once in Engineers Mode, enter the Engineers Code again. The partition test facility will be displayed.

MAKE SURE ALL PARTITIONS ARE DISARMED BEFORE EXITING ENGINEERS MODE.

1.6 Navigating the Menu

- The menu structure is shown below. Use the **[▲]** and **[▼]** keys to navigate through the menu.

1.6.1 Menu Sections

All menu entries starting with a **[]** symbol sub-menu headings. To enter a sub-menu press the **[]** key. Functions within the sub-menus are indicated by a **[>]** symbol. Press the **[]** key to run the function. When a menu function has been completed you will be returned to the engineer menu.

1.7 Initial Power up

On initial power up the LCD keypad will display the address. This will be shown as 'Matrix Keypad ID [1]', the number in the brackets indicate the address of the keypad, to change this you must select the correct address from the dip switches – as shown in the installation manual.

1.8 Menu Structure

Menu Section	Sub-Section	Equivalent Function
SYSTEM OPTIONS	>SYSTEM OPTIONS 1	[] B 2 [] 0 [] 0
	>SYSTEM OPTIONS 2	[] B 2 [] 0 [] ^ 1 []
	>SYSTEM OPTIONS 3	[] B 2 [] 0 [] B 2 []
ZONES	>CONNECTIONS	[] B 2 [] 5 [] 0
	>ZONE TYPE	[] B 2 [] 5 [] B 2 []
	>ZONE TYPE - A	[] B 2 [] 6 [] A 1 []
	>ZONE TYPE - B	[] B 2 [] 6 [] B 2 []
	>ZONE TYPE - C	[] B 2 [] 6 [] C 3 []
	>ZONE TYPE - D	[] B 2 [] 6 [] D 4 []



Menu Section	Sub-Section	Equivalent Function
	>ZONE ATTRIB - A	[] b 2 [] 7 [] a 1 []
	>ZONE ATTRIB - B	[] b 2 [] 7 [] b 2 []
	>ZONE ATTRIB - C	[] b 2 [] 7 [] c 3 []
	>ZONE ATTRIB - D	[] b 2 [] 7 [] d 4 []
	>ZONE PARTITION	[] b 2 [] 8 [] 0
	>COPY A, TO B,C&D	[] b 2 [] 9 [] 0
▶USERS	>CODE ALLOCATION	[] c 3 [] 0 [] 0
	>CODE ATTRIBUTES	[] c 3 [] 0 [] a 1 []
	>CODE LIMITS	[] c 3 [] 0 [] b 2 []
▶KEYPADS/PROX	>ICON ALLOCATION	[] c 3 [] 5 [] 0
	>ICON PUB/PRIU	[] c 3 [] 5 [] a 1 []
	>LCD ALLOCATION	[] c 3 [] 5 [] b 2 []
	>LCD PUB/PRIU	[] c 3 [] 5 [] c 3 []
	>DISPLAY TEXT	[] c 3 [] 5 [] d 4 []
	>DISARM TEXT	[] c 3 [] 5 [] 5 []
	>ARM TEXT	[] c 3 [] 5 [] 6 []
	>RKP CONTRAST	[] c 3 [] 5 [] 7 []
	>PROX ALLOCATION	[] c 3 [] 5 [] 8 []
	>PROX PUB/PRIU	[] c 3 [] 5 [] 9 []
	>LCD LANGUAGE	[] c 3 [] 6 [] 0
▶FAULTS	>SYSTEM FAULTS	[] c 3 [] 8 [] 0
	>TAMPER ALARMS	[] c 3 [] 8 [] a 1 []
▶PARTITION OPTS	>PARTITION OPT 1	[] p 4 [] 0 [] 0
	>PARTITION OPT 2	[] p 4 [] 0 [] a 1 []
▶ARM OPTIONS	>EXIT MODES A	[] p 4 [] 5 [] 0
	>EXIT MODES B	[] p 4 [] 5 [] a 1 []
	>EXIT MODES C	[] p 4 [] 5 [] b 2 []
	>EXIT MODES D	[] p 4 [] 5 [] c 3 []
	>HOME & AWAY OPT	[] p 4 [] 5 [] d 4 []
	>ARM DEPENDANCY	[] p 4 [] 5 [] 5 []
	>KEYSWITCH MODE	[] p 4 [] 5 [] 6 []
	>NO. OF REARMS	[] p 4 [] 5 [] 7 []
▶SYSTEM TIMERS	>BELL TIME	[] 5 [] 0 [] 0
	>BELL DELAY TIME	[] 5 [] 0 [] a 1 []
	>ENTRY TIME	[] 5 [] 0 [] b 2 []
	>EXIT TIME	[] 5 [] 0 [] c 3 []

Menu Section	Sub-Section	Equivalent Function
▶OUTPUTS	>SETTLE TIME	◀ 5 _{0.0} 0 □ 4 ↴
	>AUTO ARM	◀ 5 _{0.0} 0 □ 5 ↳
	>INACT AUTO ARM	◀ 5 _{0.0} 0 □ 6 _{0.0}
	>AC FAIL DELAY	◀ 5 _{0.0} 0 □ 7 ↳
	>LINE FAIL DELAY	◀ 5 _{0.0} 0 □ 8 ↳
	>TIME LOST/GAIN	◀ 5 _{0.0} 0 □ 9 ↳
	>FOLLOW ZONE	◀ 5 _{0.0} 5 _{0.0} □ A 1 _{0.0}
	>PGM TYPE	◀ 5 _{0.0} 5 _{0.0} □ 5 _{0.0}
	>PGM OPTIONS	◀ 5 _{0.0} 5 _{0.0} □ 6 _{0.0}
▶COMMUNICATION	>ACCOUNT CODE	◀ 6 _{0.0} 0 □ 0
▶REPORTING	>UDL CODE	◀ 6 _{0.0} 0 □ A 1 _{0.0}
	>DIGIT COMM OPT 1	◀ 6 _{0.0} 0 □ B 2 _{0.0}
	>DIGIT COMM OPT 2	◀ 6 _{0.0} □ A 1 _{0.0} 0
	>TEST DIAL TIME	◀ 6 _{0.0} 0 □ C 3 _{0.0}
	>TST DIAL PERIOD	◀ 6 _{0.0} 0 □ D 4 _{0.0}
	>DIAL SEQUENCE 1	◀ 6 _{0.0} 0 □ 5 _{0.0}
	>DIAL SEQUENCE 2	◀ 6 _{0.0} 0 □ 6 _{0.0}
	>DIAL SEQUENCE 3	◀ 6 _{0.0} 0 □ 7 _{0.0}
	>TEST DIAL ORDER	◀ 6 _{0.0} 0 □ 8 _{0.0}
	>ANTICODE PREFIX	◀ 6 _{0.0} 0 □ 9 _{0.0}
▶SEND OPTIONS	>TEL No. ONLY	◀ 6 _{0.0} 5 _{0.0} □ A 1 _{0.0}
	>TEL FORMAT ONLY	◀ 6 _{0.0} 5 _{0.0} □ B 2 _{0.0}
	>DIGIT CHAN'L MAP	◀ 6 _{0.0} 5 _{0.0} □ 5 _{0.0}
▶MAINTENANCE	>DISARM SIGNALS	◀ 7 _{0.0} 0 □ 0
	>ARM A SIGNALS	◀ 7 _{0.0} 0 □ A 1 _{0.0}
	>ARM B SIGNALS	◀ 7 _{0.0} 0 □ B 2 _{0.0}
	>ARM C SIGNALS	◀ 7 _{0.0} 0 □ C 3 _{0.0}
	>ARM D SIGNALS	◀ 7 _{0.0} 0 □ D 4 _{0.0}
	>DIGI RESTORALS	◀ 7 _{0.0} 0 □ 5 _{0.0}
	>EVENT PHONE No.	◀ 7 _{0.0} 0 □ 6 _{0.0}
	>VOICE MODULE	◀ 7 _{0.0} 0 □ 7 _{0.0}
	>VOICE DIALS	◀ 7 _{0.0} 0 □ 9 _{0.0}

Menu Section	Sub-Section	Equivalent Function
►DD243	>DEVICE SCAN	[◀] 7 ^U 5 ^M ▶ 4 ^L
	>RS232 UDL	[◀] 7 ^U 5 ^M ▶ 5 ^L
	>BATT CHARGE TEST	[◀] 7 ^U 5 ^M ▶ 6 ^R
	>PANEL VERSION	[◀] 7 ^U 5 ^M ▶ 7 ^L
	>CHANGE ENG CODE	[◀] A 1 ^A B 2 ^B ▶ 5 ^L
►RADIO EXPANDER	>DD243 OPT 1	[◀] 8 ^U 0 ^M ▶ 0 ^L
	>DD243 ZONE MAP	[◀] 8 ^U 0 ^M ▲ 1 ^A
	>CONFIRM TIME	[◀] 8 ^U 0 ^M ▶ 4 ^L
	>PROGRAM KEYFOB	[◀] 9 ^U 0 ^M ▶ 0 ^L
	>SUPERVISION TIME	[◀] 9 ^U 0 ^M ▲ 1 ^A

2. ACCESSING USER FUNCTIONS

Whilst in Engineer Mode all master user options, apart from changing user codes, are accessible by prefixing the user option number by **1**:

Function Number	Master User Options
	– Arm with omits (bypass)
	– View event log
	– Change keypad sounder volume*
	– Change keypad brightness*
	– View date and time
	– Change reader sounder volume*
	– Change system time
	– Change system date
	– Pulse PGM
	– Open 1hr download window
	– Proximity card allocating
	– Add Key fobs

***NOTE: These functions terminate by exiting Engineer mode.**

Engineer Mode allows you to arm and disarm the panel if the first three digits of the engineer code do not coincide with the numbers of programming functions and engineer commands, and also if the first digit is not equal to 0. For instance, if the engineer code is 9999, by entering in Engineer Mode you can access the arm/disarm commands and reset the alarm panel in the same way as with a Master User Code allocated in all partitions.

3. CHANGE ENGINEER CODE (FUNCTION 125)

Press A 1 B 2 C 3 D 4 E 5 F 6.	<i>This starts the function</i>	ENTER NEW CODE -----
Enter a 4, 5 or 6-digit engineer code.	<i>Example shows a 4-digit engineer code</i>	ENTER NEW CODE *****__
Press to accept the code. NOTE: If a 6-digit code is used, the code will be accepted automatically.		REPEAT NEW CODE -----
Re-enter the 4, 5 or 6-digit engineer code.	<i>Example shows a 4-digit engineer code</i>	REPEAT NEW CODE *****__
Press to accept the code. NOTE: If a 6-digit code is used, the code will be accepted automatically.		

4. SYSTEM OPTIONS

4.1 System Options 1 (Function 200)

Press  .	<i>This starts the function</i>	SYSTEM OPTIONS 1 OPTION 1 OFF
The current system options are displayed. Select any option by using the  and  keys, or use the  –  keys to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.	<i>There are 8 options</i>	SYSTEM OPTIONS 1 OPTION 1 OFF OPTION 2 ON OPTION 3 OFF OPTION 4 OFF OPTION 5 OFF OPTION 6 OFF OPTION 7 OFF OPTION 8 OFF

Nº	OPTION OFF	OPTION ON
1	AC Fail Warning Enabled	AC Fail Warning Disabled
2	Battery Monitoring Disabled	Battery Monitoring Enabled
3	Link Only NVM Reset	Engineer Code and Link NVM Reset
4	No Limit Log & Event Reporting	Limit Log & Event Reporting (16 Events)
5	Telephone Line Fail Fault Indication Only	Telephone Line Fail Alarm & Fault Indication
6	Global Tamper 0V Removed	Global Tamper 0V Applied
7	50Hz AC Frequency	60Hz AC Frequency
8	AC Derived Real Time Clock	Quartz Derived Real Time Clock

Shaded = Default

4.2 System Options 2 (Function 201)

Press  .	<i>This starts the function</i>	SYSTEM OPTIONS 2 OPTION 1 ON
The current system options are displayed. Select any option by using the  and  keys, or use the  –  keys to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.	<i>There are 8 options</i>	SYSTEM OPTIONS 2 OPTION 1 ON OPTION 2 ON OPTION 3 ON OPTION 4 OFF OPTION 5 OFF OPTION 6 OFF OPTION 7 OFF OPTION 8 OFF

Nº	OPTION OFF	OPTION ON
1	Fault Warning on Device Missing	Tamper Alarm on Device Missing
2	Do not put zone restorals in the log	Put zone restorals in the log
3	Spare	Spare
4	Disallow arm when H,P,I,F,M zones are open	Allow arm when H,P,I,F,M zones are open
5	Immediate zones open on exit does not cause an alarm	Immediate zones open on exit causes an alarm
6#	Do not suspend exit timer on open zone	Suspend exit timer on open zone
7	Do not enable Bell/GT EOL	Allow Bell/GT EOL
8	Allow users with proximity cards AND user codes to use codes all the time	Allow users with proximity cards AND user codes to use codes to disarm whilst armed, after alarm only

Shaded = Default

#NOTE: Italy – This option MUST be set to OFF to conform to CEI79.
Belgium - This option MUST be set to OFF to conform to T014.

Important Notes About The Wireless System

Please note that when the Matrix system recognises that a Wireless Expander has been installed, the following options will be automatically changed as shown in the table below. Please see the following page for the original defaults.

 - System Options 2,

Nº	OPTION	System Options 2	 OFF	 ON
4	Allow Arm If H, I, P, F, M, T Zones Open*		No	[Yes]
5	Immediate Zones Open On Exit		[Does Not Cause Alarm]	Cause Alarm
6	Suspend Exit Timer On Open Zone*  		No	[Yes]

Systems Options 2, Option 6: Suspend Exit Timer On Open Zone

This function will be set to YES and disabled from the system completely.

4.3 System Options 3 (Function 202)

Press  .	<i>This starts the function</i>	SYSTEM OPTIONS 3 OPTION 1 OFF
The current system options are displayed. Select any option by using the  and  keys, or use the  –  keys to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.	<i>There are 6 options</i>	SYSTEM OPTIONS 3 OPTION 1 OFF OPTION 2 OFF OPTION 3 ON OPTION 4 OFF OPTION 5 OFF OPTION 6 ON

Nº	OPTION OFF	OPTION ON
1	Do not hide the display	Hide display after 20 seconds of keypad inactivity
2	Restore battery faults as they occur	Restore battery faults when exit engineer mode
3	Display ALARM in FTA mode	Display ALARM as alarms occur
4*	Allow arming during mains fail	Disallow arm during mains fail
5*	Allow arm with battery fault	Disallow arm with battery fault
6#	Tamper on user omitted zones does not cause alarm	Tamper on user omitted zones does cause alarm
7	Wireless jamming fault When armed does not cause tamper	Wireless jamming fault when armed causes tamper
8	Allow Wireless keyfob disarm during entry period only	Allow Wireless keyfob disarm always

Shaded = Default

***NOTE: Belgium - This option MUST be set to ON to comply with T014.**

#NOTE: Belgium - This option MUST be set to Causes Alarm to comply with T014.

5. ZONES

5.1 Zone Connections (Function 250)

Press  .	<i>This starts the function</i>	ZONE CONNECTIONS OPTION 1 OFF
The current system options are displayed. Select any option by using the  and  keys, or use the  –  keys to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.	<i>There are 4 options</i>	ZONE CONNECTIONS OPTION 1 OFF OPTION 2 OFF OPTION 3 OFF OPTION 4 OFF

Nº	OPTION OFF	OPTION ON
1*	With End of Line Resistors	Without End of Line Resistors
2	Zone Doubling Disabled	Zone Doubling Enabled
3	350ms All Zones	100ms All Zones (fast zones)
4#	Zone 1: 30ms Zone - Disabled	Zone 1: 30ms Zone - Enabled
5	Single End of Line Zones (Alarm zones - no tamper) - Disabled	Single End of Line Zones (Alarm zones – no tamper) - Enabled


Shaded = Default.

NOTE: Using Zone Doubling it is possible to wire up to 64 zones (see installation manual)

***NOTE: Italy – To comply with CEI79 Level 2, zones MUST be DEOL.**

#NOTE: Italy – To comply with CEI79, this option must only be enabled if Zone 1 is connected to an inertia detector.

5.2 Zone Names on LCD Keypad (Function 252)

Press  .	<i>The current zone name is displayed for Zone 1.</i>	SELECT ZONE 01 >ZONE 1
Use the following keys to select a zone name to edit:  = Increment by 1  = Decrement by 1  = Increment by 10  = Decrement by 10 Press  to select the zone.	<i>For example Zone 6</i>	SELECT ZONE 06 >ZONE 6
A flashing cursor is placed over the first character of the zone name. Use the  and  keys to move the cursor to the desired position. Use the  –  keys to change the character displayed at the current cursor position (see table below). Repeat for all characters as required. Press  to accept the changes. The flashing cursor is removed. You may now select another zone to change.	<i>Example shows changing ZONE 6 to ZONE SIX</i>	EDIT TEXT 06 >ZONE 6 EDIT TEXT 06 >ZONE S EDIT TEXT 06 >ZONE SI EDIT TEXT 06 >ZONE SIX
To exit the function press the  key.		

The following tables show how to obtain certain characters when programming user names, zone names, etc. Each time you press the same numerical key, the next character is chosen. There are three tables shown. Use only the table that corresponds to the LCD keypad language setting as some keys will vary.

RUSSIAN / BULGARIAN																													
Key	Number of key presses																	Key	Number of key presses										
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	1	2	3	4	5	6	7	8	9	10	11	
①	A	B	C	1	À	Á	Ã	Ä	Å	Æ	Ӯ	҃	҆	҈	҉	Ҋ	ҋ	⑥	P	Q	R	6	8	Σ	҂	҄	҅	҇	
②	D	E	F	2	È	É	Ê	Ë	Ӧ	Ӯ	Ӱ	Ӳ	Ӵ	Ӷ	Ӹ	ӹ	ӻ	⑦	S	T	U	7	Ӱ	Ӱ	Ӱ	Ӱ	Ӱ	Ӱ	
③	G	H	I	3	ѝ	í	î	ї	ë	ѧ	҂	҄	҆	҈	҉	Ҋ	ҋ	⑧	ӱ	Ӳ	ӳ	ӵ	ӷ	Ӹ	ӹ	ӻ	Ӵ	Ӷ	
④	J	K	L	4	Ж	҃	҄	҅	҆	҈	҉	Ҋ	ҋ	Ҍ	ҍ	Ҏ	ҏ	⑨	ӽ	Ӿ	ӷ	Ӹ	ӹ	ӻ	Ӵ	Ӷ	ӹ	ӻ	
⑤	M	N	O	5	Ӯ	Ӱ	Ӳ	Ӵ	Ӷ	Ӹ	ӹ	ӻ	Ӵ	Ӷ	Ӹ	ӹ	ӻ	⑩	Ӱ	ӻ	Ӵ	Ӷ	Ӹ	ӹ	ӻ	Ӵ	Ӷ	Ӹ	
CZECH																													
Key	Number of key presses																	Key	Number of key presses										
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	1	2	3	4	5	6	7	8	9	10	11	
①	A	B	C	1	À	Á	Ã	Ä	Å	Æ	Ӯ	҃	҆	҈	҉	Ҋ	ҋ	⑥	P	Q	R	6	8	Σ	҂	҄	҅	҇	
②	D	E	F	2	È	É	Ê	Ë	Ӧ	Ӯ	Ӱ	Ӳ	Ӵ	Ӷ	Ӹ	ӹ	ӻ	⑦	S	T	U	7	Ӱ	Ӱ	Ӱ	Ӱ	Ӱ	Ӱ	
③	G	H	I	3	ѝ	í	î	ї	ë	ѧ	҂	҄	҆	҈	҉	Ҋ	ҋ	⑧	ӱ	Ӳ	ӳ	ӵ	ӷ	Ӹ	ӹ	ӻ	Ӵ	Ӷ	
④	J	K	L	4	Ж	҃	҄	҅	҆	҈	҉	Ҋ	ҋ	Ҍ	ҍ	Ҏ	ҏ	⑨	ӽ	Ӿ	ӷ	Ӹ	ӹ	ӻ	Ӵ	Ӷ	ӹ	ӻ	
⑤	M	N	O	5	Ӯ	Ӱ	Ӳ	Ӵ	Ӷ	Ӹ	ӹ	ӻ	Ӵ	Ӷ	Ӹ	ӹ	ӻ	⑩	Ӱ	ӻ	Ӵ	Ӷ	Ӹ	ӹ	ӻ	Ӵ	Ӷ	Ӹ	
GREEK																			Number of key presses										
Key	Number of key presses																	Key	Number of key presses										
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	1	2	3	4	5	6	7	8	9	10	11	
①	A	B	C	1	À	Á	Ã	Ä	Å	Æ	Ӯ	҃	҆	҈	҉	Ҋ	ҋ	⑥	P	Q	R	6	8	Σ	҂	҄	҅	҇	
②	D	E	F	2	È	É	Ê	Ë	Ӧ	Ӯ	Ӱ	Ӳ	Ӵ	Ӷ	Ӹ	ӹ	ӻ	⑦	S	T	U	7	Ӱ	Ӱ	Ӱ	Ӱ	Ӱ	Ӱ	
③	G	H	I	3	ѝ	í	î	ї	ë	ѧ	҂	҄	҆	҈	҉	Ҋ	ҋ	⑧	ӱ	Ӳ	ӳ	ӵ	ӷ	Ӹ	ӹ	ӻ	Ӵ	Ӷ	
④	J	K	L	4	Ж	҃	҄	҅	҆	҈	҉	Ҋ	ҋ	Ҍ	ҍ	Ҏ	ҏ	⑨	ӽ	Ӿ	ӷ	Ӹ	ӹ	ӻ	Ӵ	Ӷ	ӹ	ӻ	
⑤	M	N	O	5	Ӯ	Ӱ	Ӳ	Ӵ	Ӷ	Ӹ	ӹ	ӻ	Ӵ	Ӷ	Ӹ	ӹ	ӻ	⑩	Ӱ	ӻ	Ӵ	Ӷ	Ӹ	ӹ	ӻ	Ӵ	Ӷ	Ӹ	
ALL OTHER LANGUAGES																			Number of key presses										
Key	Number of key presses																	Key	Number of key presses										
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	1	2	3	4	5	6	7	8	9	10	11	
①	A	B	C	1	À	Á	Ã	Ä	Å	Æ	Ӯ	҃	҆	҈	҉	Ҋ	ҋ	⑥	P	Q	R	6	8	Σ	҂	҄	҅	҇	
②	D	E	F	2	È	É	Ê	Ë	Ӧ	Ӯ	Ӱ	Ӳ	Ӵ	Ӷ	Ӹ	ӹ	ӻ	⑦	S	T	U	7	Ӱ	Ӱ	Ӱ	Ӱ	Ӱ	Ӱ	
③	G	H	I	3	ѝ	í	î	ї	ë	ѧ	҂	҄	҆	҈	҉	Ҋ	ҋ	⑧	ӱ	Ӳ	ӳ	ӵ	ӷ	Ӹ	ӹ	ӻ	Ӵ	Ӷ	
④	J	K	L	4	Ж	҃	҄	҅	҆	҈	҉	Ҋ	ҋ	Ҍ	ҍ	Ҏ	ҏ	⑨	ӽ	Ӿ	ӷ	Ӹ	ӹ	ӻ	Ӵ	Ӷ	ӹ	ӻ	
⑤	M	N	O	5	Ӯ	Ӱ	Ӳ	Ӵ	Ӷ	Ӹ	ӹ	ӻ	Ӵ	Ӷ	Ӹ	ӹ	ӻ	⑩	Ӱ	ӻ	Ӵ	Ӷ	Ӹ	ӹ	ӻ	Ӵ	Ӷ	Ӹ	

5.3 Zone Type – Arm Mode A (Function 261)**5.4 Zone Type – Arm Mode B (Function 262)****5.5 Zone Type – Arm Mode C (Function 263)****5.6 Zone Type – Arm Mode D (Function 264)**

Programming for Arm Mode A is shown.

Press 		ENTER ZONE No. ---
Enter the zone number to configure as a 2-digit number (01 – 32). *If zone doubling is selected it is possible to program up to 64 zones	<i>Example shows Zone 01. This display is quickly followed by the next.</i>	ENTER ZONE No. 01
The current zone type is displayed. Use the  and  keys to scroll through the zone types, or type a 2-digit zone code to select the zone type. Press  to accept the zone type.	00 = ENTRY / EXIT 01 = ACCESS 02 = IMMEDIATE 03 = OMIT 04 = FIRE ALARM 05 = PERSONAL ATTACK 06 = 24 HOUR 07 = KEY BOX 08 = SHUNT KEYPAD 09 = TAMPER 10 = LATCHED KEY 11 = MOMENTARY KEY 12 = UNUSED 13 = MEDICAL 14 = ARM	ARM MODE A ENTRY/EXIT

DEFAULT ZONE TYPES

Zone	Type	Zone	Type	Zone	Type	Zone	Type
1	Entry/Exit	9	Immediate	17	Immediate	25	Immediate
2	Access	10	Immediate	18	Immediate	26	Immediate
3	Immediate	11	Immediate	19	Immediate	27	Immediate
4	Immediate	12	Immediate	20	Immediate	28	Immediate
5	Immediate	13	Immediate	21	Immediate	29	Immediate
6	Immediate	14	Immediate	22	Immediate	30	Immediate
7	Immediate	15	Immediate	23	Immediate	31	Immediate
8	Immediate	16	Immediate	24	Immediate	32	Immediate
33	Immediate	41	Immediate	49	Immediate	57	Immediate
34	Immediate	42	Immediate	50	Immediate	58	Immediate
35	Immediate	43	Immediate	51	Immediate	59	Immediate
36	Immediate	44	Immediate	52	Immediate	60	Immediate
37	Immediate	45	Immediate	53	Immediate	61	Immediate
38	Immediate	46	Immediate	54	Immediate	62	Immediate
39	Immediate	47	Immediate	55	Immediate	63	Immediate
40	Immediate	48	Immediate	56	Immediate	64	Immediate

(In grey – zones that can only be used if Zone doubling is selected (See Function 250)

5.7 Zone Attributes – Arm Mode A (Function 271)**5.8 Zone Attributes – Arm Mode B (Function 272)****5.9 Zone Attributes – Arm Mode C (Function 273)****5.10 Zone Attributes – Arm Mode D (Function 274)**

Programming for Arm Mode A is shown.

Press 		ENTER ZONE No. --
Enter the zone number to configure as a 2-digit number (01 – 32). *If zone doubling is selected it is possible to program up to 64 zones	<i>Example shows Zone 01. This display is quickly followed by the next.</i>	ENTER ZONE No. 01
The current zone attributes are displayed. Select any attribute by using the  and  keys, or use the  –  keys to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.		ARM MODE A OPTION 1 OFF

Nº	OPTION OFF	OPTION ON
1	Chime Disabled	Chime Enabled
2	Test Disabled	Test Enabled
3	Mask Disabled	Mask Enabled
4	Double Knock Disabled	Double Knock Enabled
5	Normally Closed	Normally Open
6	Reserved for Future Use. Do Not Alter.	
7		
8		

Shaded = Default

5.11 Zone Partition (Function 280)

Press  .		ENTER ZONE No. ---
Enter the zone number to configure as a 2-digit number (01 – 32). *If zone doubling is selected it is possible to program up to 64 zones	<i>Example shows Zone 01. This display is quickly followed by the next.</i>	ENTER ZONE No. 01
The current partition is displayed. Enter a partition  . Press  to assign the zone to the partition.		ENTER PARTITION 1

NOTE: By default all zones are assigned to Partition 1.

5.12 Copy Arm A to B,C & D (Function 290)

Press  .		COPY A TO B,C&D SYSTEM BUSY
When complete you will be returned to Engineer Mode.		

6. USERS

6.1 User Code Partition (Function 300)

Press  .		ENTER USER No. --
Enter the 2-digit user number (01 – 32).	<i>Example shows User 01. This display is quickly followed by the next.</i>	ENTER USER No. 01
The current user partitions are displayed. Select any option (partition) by using the  and  keys, or use the  –  keys to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.	<i>There are 4 options</i>	CODE ALLOCATION OPTION 1 ON OPTION 2 OFF OPTION 3 OFF OPTION 4 OFF

Nº	OPTION OFF	OPTION ON
1	User Code Not Assigned to Partition 1	User Code Assigned to Partition 1
2	User Code Not Assigned to Partition 2	User Code Assigned to Partition 2
3	User Code Not Assigned to Partition 3	User Code Assigned to Partition 3
4	User Code Not Assigned to Partition 4	User Code Assigned to Partition 4
5		
6		
7		
8		

Shaded = Default

Reserved for Future Use. Do Not Alter.

6.2 User Code Attributes (Function 301)

Press 		ENTER USER No. --
Enter the 2-digit user number (01 – 32).	<i>Example shows User 01. This display is quickly followed by the next.</i>	ENTER USER No. 01
The current user attributes are displayed. Select any attribute by using the  and  keys, or use the  –  keys to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.	<i>There are 6 options</i>	CODE ALLOCATION OPTION 1 ON OPTION 2 OFF OPTION 3 OFF OPTION 4 OFF

Nº	OPTION OFF	OPTION ON
1	Disallow Omit (Bypass) Zones	Allow Omit (Bypass) Zones
2	Normal User Code	Duress Code Only
3	Duress Code Disabled	Duress Code Enabled
4	Disallow Arm	Allow Arm
5	Disallow Disarm	Allow Disarm
6	Disallow Forced Re-arm	Allow Forced Re-arm
7	Reserved For Future Use.	
8	Limited User Code (default for Users 02 – 32)	Master User Code (default for User 01)

Shaded = Default

6.3 Temporary Code (Function 302)

Press 		ENTER USER No. --
Enter the 2-digit user number (01 – 32).	<i>Example shows User 01. This display is quickly followed by the next.</i>	ENTER USER No. 01
The maximum uses for this code is displayed.	<i>Example shows 10 uses.</i>	CODE LIMITS 10
Enter the new maximum use value as a 2-digit number (00 – 99). Press  to accept the changes.	<i>Example shows 4 uses</i>	CODE LIMITS 04

VALUE	DESCRIPTION
00	Unlimited uses of this code
01	After 1 use the code is deleted
02-99	Number of times this code can be used between any use of an unlimited code

7. KEYPADS/PROXIMITY READERS

7.1 ICON Partition Allocation (Function 350)

Press  c 3  5  0.		ENTER KEYPAD ID —
Enter the keypad ID number (1 – 4).	<i>Example shows keypad ID 1 This display is quickly followed by the next.</i>	ENTER KEYPAD ID —1
The current partition is displayed.	<i>Example shows Partition 1 only</i>	ENTER PARTITIONS — 1
Press the  –  buttons to assign the keypad to any of the partitions as required.	<i>Example shows partitions 1 & 3 selected</i>	ENTER PARTITIONS — 13
Press  to accept the changes.		

NOTE: By default all ICON keypads are assigned to Partition 1.

7.2 ICON Public/Private (Function 351)

Press  c 3  5   .		ENTER KEYPAD ID —
Enter the keypad ID number (1 – 4).	<i>Example shows keypad ID 1 This display is quickly followed by the next.</i>	ENTER KEYPAD ID —1
The current options are displayed. Select any attribute by using the  and  keys, or use the  key to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.	<i>There is 1 option</i>	ICON PUB/PRIU OPTION 1 OFF

Nº	OPTION OFF	OPTION ON
1	Public Keypad	Private Keypad
2		
3		
4		
5		Reserved for Future Use. Do Not Alter.
6		
7		
8		

Shaded = Default

7.3 LCD Partition Allocation (Function 352)

Press  .		ENTER KEYPAD ID —
Enter the keypad ID number (1 – 4).	<i>Example shows keypad ID 1 This display is quickly followed by the next.</i>	ENTER KEYPAD ID —1
The current partition is displayed.	<i>Example shows Partition 1 only</i>	ENTER PARTITIONS — 1
Press the  –  buttons to assign the keypad to any of the partitions as required.	<i>Example shows partitions 1 & 3 selected</i>	ENTER PARTITIONS — 13
Press  to accept the changes.		

NOTE: By default all LCD keypads are assigned to Partition 1.

7.4 LCD Public/Private (Function 353)

Press  .		ENTER KEYPAD ID —
Enter the keypad ID number (1 – 4).	<i>Example shows keypad ID 1 This display is quickly followed by the next.</i>	ENTER KEYPAD ID —1
The current options are displayed. Select any attribute by using the  and  key to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.	<i>There is 1 option</i>	LCD PUB/PRIU OPTION 1 OFF

Nº	OPTION OFF	OPTION ON
1	Public Keypad	Private Keypad
2		
3		
4		
5		Reserved for Future Use. Do Not Alter.
6		
7		
8		

Shaded = Default

7.5 Change Label Messages (Function 354)

Press  .		SELECT LABEL 01 >DISARMED
Select any message by using the  and  keys.	<i>Example shows message 6.</i>	SELECT LABEL 06 >ARMED
Press  to select the message for editing. A flashing cursor is placed over the first character of the message		EDIT TEXT 06 >ARMED
Use the  and  keys to move the cursor to the desired character position.	<i>Example shows message 6 being changed from ARMED to PANEL ARMED</i>	EDIT TEXT 06 >ARMED
Use the  –  keys to change the character displayed at the current cursor position (see the table on page 14). Repeat for all characters as required.		EDIT TEXT 06 >PANEL ARMED
Press  to accept the changes.		EDIT TEXT 06 >PANEL ARMED

DEFAULT MESSAGE TYPE	KEYPAD ID	MESSAGE NUMBER
Disarmed Mode Message	1-4	1-4
Armed Mode Message	1-4	5-8
Pulse PGM User Menu Message	1-4	27-30
Welcome Engineer Message	All Keypads	31 (top) – 32 (bottom)

7.6 Assign Disarmed Labels (Function 355)

Press  .		ENTER KEYPAD ID _< [1-4]
Enter the keypad ID number (1 – 4).	<i>Example shows keypad 1 This display is quickly followed by the next</i>	ENTER KEYPAD ID 1< [1-4]
The first message is displayed.		DAY LABEL 01 >DISARMED
Use the  and  keys to select the desired message.	<i>Example shows message 9</i>	DAY LABEL 09 >LABEL 9
Press  to accept the changes.		

7.7 Assign Armed Labels (Function 356)

Press  .		ENTER KEYPAD ID _< [1-4]
Enter the keypad ID number (1 – 4).	<i>Example shows keypad 1 This display is quickly followed by the next</i>	ENTER KEYPAD ID 1< [1-4]
The first message is displayed.		ARMED LABEL 01 >DISARMED
Use the  and  keys to select the desired message.	<i>Example shows message 12</i>	ARMED LABEL 12 >LABEL 12
Press  to accept the changes.		

7.8 LCD Contrast (Function 357)

Press  .		ADJUST CONTRAST USE UP-DOWN KEYS
Use the  and  keys to increase or decrease the contrast of the display.		ADJUST CONTRAST USE UP-DOWN KEYS
Press  to accept the changes.		

7.9 Proximity Reader Partition Allocation (Function 358)

Press  .		ENTER PROX ID _
Enter the proximity reader ID number (1 – 4).	<i>Example shows reader ID 1 This display is quickly followed by the next.</i>	ENTER PROX ID _ 1
The current partition is displayed.	<i>Example shows Partition 1 only</i>	ENTER PARTITIONS _ 1
Press the  –  buttons to assign the reader to any of the partitions as required.	<i>Example shows partitions 1 & 3 selected</i>	ENTER PARTITIONS _ 13
Press  to accept the changes.		

NOTE: By default all Proximity Readers are assigned to Partition 1.

7.10 Proximity Reader Public/Private (Function 359)

Press [↴ c 3 ⌂ 5 ⌂ 9 ⌂] .		ENTER PROX ID _
Enter the proximity reader ID number (1 – 4).	<i>Example shows reader ID 1 This display is quickly followed by the next.</i>	ENTER PROX ID _ 1
The current options are displayed. Select any attribute by using the ▲ and ▼ keys, or use the [A] key to select that option directly. Press [🔒] to toggle the option ON or OFF. Press [↴] to accept the options.	<i>There is 1 option</i>	PROX PUB/PRIU OPTION 1 OFF

Nº	OPTION OFF	OPTION ON
1	Public Proximity Reader	Private Proximity Reader
2		
3		
4		
5		Reserved for Future Use. Do Not Alter.
6		
7		
8		

Shaded = Default

7.11 LCD Keypad Language (Function 360)

Press [↴ c 3 ⌂ 6 ⌂ 0] .		ENTER KEYPAD ID _ < [1-4]
Enter the LCD keypad ID number (1 – 4).	<i>The first language is displayed</i>	SELECT LANGUAGE >ENGLISH
Use the ▲ and ▼ keys to scroll through the list of available languages. NOTE: UK English keypads only have the UK English language installed.	<i>There are several different keypads available, all with different languages installed.</i>	SELECT LANGUAGE >ENGLISH >SPANISH >ITALIANO >Les Francais >PORTUGUESE
Press [↴] to accept the changes.		

NOTE: The language change will only take effect after exiting Engineer Mode.

8. FAULTS

8.1 System Fault Partition (Function 380)

Press  .	<i>This display is quickly followed by the next</i>	ENTER PARTITIONS —
The current partition warning allocation is displayed.	<i>Example shows partition 1 only</i>	ENTER PARTITIONS — 1000
Select all partitions that you want system faults to display in. Entering 0 as the first entry will allocate system fault displays to all partitions.	<i>Example shows partitions 1 & 3</i>	ENTER PARTITIONS 13
Press  to accept the changes. NOTE: If 4 digits are entered they are automatically accepted.		

NOTE: By default all system faults are displayed in Partition 1 only.

8.2 Bell/Tamper Fault Partition (Function 381)

Press  .	<i>This display is quickly followed by the next</i>	ENTER PARTITIONS —
The current bell/tamper fault partition allocation is displayed.	<i>Example shows partition 1 only</i>	ENTER PARTITIONS — 1000
Select all partitions that you want bell and tamper faults to display in. Entering 0 as the first entry will allocate bell and tamper fault displays to all partitions.	<i>Example shows partitions 1 & 3</i>	ENTER PARTITIONS 13
Press  to accept the changes. NOTE: If 4 digits are entered they are automatically accepted.		

NOTE: By default all bell / tamper faults are displayed in Partition 1 only.

9. PARTITION OPTIONS

9.1 Partition Options 1 (Function 400)

Press  .	<i>This starts the function</i>	ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
The current partition options are displayed. Select any option by using the  and  keys, or use the  –  keys to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.	<i>There are 8 options</i>	PARTITION OPT 1 OPTION 1 ON OPTION 2 OFF OPTION 3 OFF OPTION 4 ON OPTION 5 ON OPTION 6 OFF OPTION 7 OFF OPTION 8 ON

Nº	OPTION OFF	OPTION ON
1	Audible PA Alarm	Silent PA Alarm
2	Reserved for Future Use. Do Not Alter.	
3	Internal Sirens Only on Tamper Alarm	Internal & External Sirens on Tamper Alarm
4	Do Not Display Open Zones when Disarmed	Display Open Zones when Disarmed
5	Do Not Omit (Bypass) Open Zones on Rearm	Omit (Bypass) Open Zones on Rearm
6	Bell Squawk Off	Bell Squawk On
7	Kiss-Off Confirmation Tone Off	Kiss-Off Confirmation Tone On
8	Do Not Display Open Zones in Alarm	Display Open Zones in Alarm

Shaded = Default

9.2 Partition Options 2 (Function 401)

Press  .	<i>This starts the function</i>	ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
The current partition options are displayed. Select any option by using the  and  keys, or use the  –  keys to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.	<i>There are 6 options</i>	PARTITION OPT 2 OPTION 1 OFF OPTION 2 OFF OPTION 3 OFF OPTION 4 OFF OPTION 5 OFF OPTION 6 ON

Nº	OPTION OFF	OPTION ON
1	Bell Time in Minutes	Bell Time in Seconds
2	Anti-Code Reset disabled	Anti-Code Reset Enabled
*3	Engineer Reset Disabled	Engineer Reset Enabled
*4	Reset required After Confirmed Alarms	Reset Required After All Alarms
5	Normal Sounder Operation	French Sounder Operation
6	Do Not Allow Zone Restorals After Reset	Allow Zone Restorals After Reset
7	Reserved for Future Use. Do Not Alter.	
8	Reserved for Future Use. Do Not Alter.	

Shaded = Default

*IMPORTANT NOTE ON ENGINEER RESET

Please note that if the below options are both turned ON; an Engineer Reset is only needed for any TAMPER ALARMS.

A user code will be able to reset ALL OTHER ALARMS.

OPTION NUMBER 3 = ENGINEER RESET ENABLED

OPTION NUMBER 4 = RESET REQUIRED AFTER ALL ALARMS

10. ARM OPTIONS

10.1 Exit Terminator – Arm Mode A (Function 450)

10.2 Exit Terminator – Arm Mode B (Function 451)

10.3 Exit Terminator – Arm Mode C (Function 452)

10.4 Exit Terminator – Arm Mode D (Function 453)

Programming for Arm Mode A is shown.


Press  4  5  .		ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION —1
The current exit terminator type is shown.	<i>Example shows Final Exit (type 01)</i>	EXIT MODES A 01
Enter 1 digit for the required exit terminator type (1 – 4). NOTE: A leading zero is always shown.	<i>Example shows Silent Arm (type 02)</i>	EXIT MODES A 02
Press  to accept the changes.		

Nº	EXIT TERMINATOR TYPE
00	Timed Exit
01	Final Exit
02	Silent Arm
03	Push to Arm
04	Forced Arm

Shaded = Default

Note: If the wireless function 'quick arm' is used then the exit timer is suspended. If the user doesn't want the exit timer to be suspended on an open zone in silent set then the key fob must not use the quick arm option. The normal timed arm option should be used with a long exit timer.

10.5 Home & Away Allocation (Function 454)

Press  .	<i>This starts the function</i>	ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
The home & away options are displayed. Select any option by using the  and  keys, or use the  –  keys to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.	<i>There are 4 options</i>	

Nº	OPTION OFF	OPTION ON
1 – Arm Mode A	Home	Away
2 – Arm Mode B	Home	Away
3 – Arm Mode C	Home	Away
4 – Arm Mode D	Home	Away
5		
6		
7		
8		

Shaded = Default

10.6 Partition Dependency (Function 455)

Press  .	<i>This starts the function</i>	ENTER PARTITION _
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
The current partition options are displayed. Select any option by using the  and  keys, or use the  –  keys to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.	<i>There are 4 options</i>	ARM DEPENDANCY OPTION 1 OFF OPTION 2 OFF OPTION 3 OFF OPTION 4 OFF

Nº	OPTION OFF	OPTION ON
1	Partition Will Not Arm with Partition 1	Partition Will Arm with Partition 1
2	Partition Will Not Arm with Partition 2	Partition Will Arm with Partition 2
3	Partition Will Not Arm with Partition 3	Partition Will Arm with Partition 3
4	Partition Will Not Arm with Partition 4	Partition Will Arm with Partition 4
5		
6		
7		
8		

Shaded = Default

10.7 Keyswitch Arm Mode Allocation (Function 456)

Press  .		ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
The current setting is displayed. Enter 1 digit for the new arm mode (1 – 4). NOTE: A leading zero is always shown.	<i>Example shows Arm Mode A</i>	ENTER ARM MODE 01
Press  to accept the changes.		

Nº ARM MODE ALLOCATION	
01	Arm Mode A
02	Arm Mode B
03	Arm Mode C
04	Arm Mode D

Shaded = Default

10.8 Number of Rearms (Function 457)

Press  .		ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
The current setting is displayed.	<i>Example shows Continuous Rearms (type 00)</i>	NUMBER OF REARMS 00
Enter 1 digit for the new value (1 – 9). NOTE: A leading zero is always shown.	<i>Example shows 3 rearms</i>	NUMBER OF REARMS 03
Press  to accept the changes.		

Nº NUMBER OF REARMS	
00	Continuous Rearms
01 - 09	Auto Arm 1 – 9 Times

Shaded = Default

11. SYSTEM TIMERS

11.1 Bell Time (Function 500)

Press  5  0  .		ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION —1
The current bell time is displayed.	<i>Example shows 04 (minutes or seconds)</i>	ENTER BELL TIME 04
Enter 2 digits for the new time (00 – 99).	<i>Example shows 30 (minutes or seconds)</i>	ENTER BELL TIME 30
Press  to accept the changes.		

NOTE: Default is 4 minutes.

11.2 Bell Time Delay (Function 501)

Press  5  0   .		ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION —1
The current bell time delay is displayed.	<i>Example shows 00 minutes</i>	ENTER BELL DELAY 00
Enter 2 digits for the new delay (00 – 99).	<i>Example shows 02 minutes</i>	ENTER BELL DELAY 02
Press  to accept the changes.		

NOTE: Default is 0 minutes.

NOTE – Italy: Bell Delay MUST be set to 0 to comply with CEI79.

11.3 Entry Time (Function 502)

Press  5  0   .		ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION —1
The current entry time is displayed.	<i>Example shows 20 seconds</i>	ENTER ENTRY TIME 20
Enter 2 digits for the new time (00 – 99).	<i>Example shows 30 seconds</i>	ENTER ENTRY TIME 30
Press  to accept the changes.		

NOTE: Default is 20 seconds.

11.4 Exit Time (Function 503)

Press  .		ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
The current exit time is displayed.	<i>Example shows 20 seconds</i>	ENTER EXIT TIME 20
Enter 2 digits for the new delay (00 – 99).	<i>Example shows 10 seconds</i>	ENTER EXIT TIME 10
Press  to accept the changes.		

NOTE: Default is 20 seconds.

11.5 Final Exit Delay (Function 504)

Press  .		ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
The current exit delay time is displayed.	<i>Example shows 07 seconds</i>	SETTLE TIME ? 07
Enter 2 digits for the new time (00 – 99).	<i>Example shows 05 seconds</i>	SETTLE TIME ? 05
Press  to accept the changes.		

NOTE: Default is 7 seconds.

11.6 Auto Arm Commence Time (Function 505)

Press  .		ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
The current time is displayed.	<i>Example shows Auto Arm disabled (0000)</i>	ENTER START TIME _0000
Enter 4 digits for the new commence time (0000 – 2359, 24-hour format). NOTE: The time is automatically accepted after entering the 4th digit.	<i>Example shows 12:26 PM</i>	ENTER START TIME 1226

NOTE: Default is 0000 (Auto Arm disabled).

NOTE: Italy – If Auto Arm is to be used, "Allow Arm If H,I,P,F,M,T Zone Open" must be set to "Yes", and "Immediate Zone Open On Exit" must be set to "Causes Alarm" (System Options 2, page 11) in order to comply with CEI79.

11.7 Inactivity Auto Arm (Function 506)

Press  .		ENTER PARTITION _
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
The current time is displayed.	<i>Example shows Inactivity Auto Arm disabled (0000)</i>	ENTER INACT TIME 00
Enter 2 digits for the new inactivity time (00 – 99). The number entered x 10 = time in minutes. NOTE: The time is automatically accepted after entering the 2nd digit.	<i>Example shows 2 hours (12 x 10 = 120 minutes)</i>	ENTER INACT TIME 12

NOTE: Default is 00 (Inactivity Auto Arm disabled).

11.8 AC Fail Warning Delay (Function 507)

Press  .	<i>The current delay time is displayed</i>	ENTER DELAY TIME 10
Enter 2 digits for the new delay time (00 – 99).	<i>Example shows 20 minutes</i>	ENTER DELAY TIME 20
Press  to accept the changes.		

NOTE: Default is 10 minutes.

11.9 Telephone Line Fail Warning Delay (Function 508)

Press  .	<i>The current delay time is displayed</i>	ENTER DELAY TIME 10
Enter 2 digits for the new delay time (00 – 99).	<i>Example shows 20 minutes</i>	ENTER DELAY TIME 20
Press  to accept the changes.		

NOTE: Default is 1 minute.

11.10 Seconds in Last Minute of Day (Function 509)

Press  .	<i>The current number of seconds is displayed</i>	ENTER SECONDS 60
Enter 2 digits for the new delay time (00 – 99).	<i>Example shows 65 seconds</i>	ENTER SECONDS 65
Press  to accept the changes.		

NOTE: Default is 60 seconds.

12. OUTPUTS

12.1 Zone to Follow in Partition (Function 551)

Press 		ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
The current zone allocated is displayed.	<i>Example shows none (00)</i>	ENTER ZONE No. 00
Enter 2 digits for the new zone number (00 – 32, 00 = none).	<i>Example shows zone 12</i>	ENTER ZONE No. 12
Press  to accept the changes.		

NOTE: Default is 00 (none).

12.2 PGM Type (Function 555)

Press 		ENTER PGM No. ---
Enter 2 digits for the PGM (01 – 12).	<i>Example shows PGM 1 This display is quickly followed by the next</i>	ENTER PGM No. 01
The current PGM type is displayed.	<i>Example shows External Bell (type 14)</i>	ENTER ZONE No. 00
Enter 2 digits for the new PGM type (00 – 30). Press  to accept the change.	<i>Example shows Follow Zone (type 05)</i>	ENTER PGM TYPE 14
The current PGM partition allocation is displayed.	<i>Example shows all partitions</i>	ENTER PARTITIONS _ 1234
Enter up to 4 digits for the partition allocation. 0 = All Partitions 1-4 = Partitions 1-4	<i>Example shows Partition 1 only</i>	ENTER PARTITIONS 1
Press  to accept the changes.		
NOTE: If 4 digits are entered they are automatically accepted.		

Defaults:

PGM TYPE	PARTITION	PGM TYPE	PARTITION
1 External Bell	1	7 Not Used	—
2 Follow Strobe	1	8 Not Used	—
3 Follow Arm/Disarm	1	9 Not Used	—
4 Follow PA Alarm	1	10 Not Used	—
5 Not Used	—	11 Not Used	—
6 Not Used	—	12 Not Used	—

12.2.1 PGM Types

Nº	Output Type	Nº	Output Type
0 0	Not Used	2 4	Follow Digital Output Confirmed Alarm
0 1	E- (LED Enable)	2 5	Follow Digital Output Omits (Bypass)
0 2	C+ (Latch)	2 6	Follow Hidden Display
0 3	RKP Controlled	2 7	Follow Mains Fail
0 4	Follow Arm/Disarm	2 8	Follow Battery Low
0 5	Follow Zone	2 9	Follow Battery Missing
0 6	Follow Tel Line Fail	3 0	Internal Sounder
0 7	Follow Kiss Off Signal	3 1	Follow Medical Alarm
0 8	Shock/Fire Sensor Reset	3 2	Follow Battery Faults
0 9	Follow Strobe	3 3	Follow Duress
1 0	Follow Fire Alarm	3 4	Follow Disarmed
1 1	Follow PA Alarm	3 5	Follow System Faults
1 2	Follow Confirmed Alarm	3 6	Follow Momentary Burglary
1 3	Follow Tamper Alarm	3 7	Follow Momentary 24HR
1 4	External Bell	3 8	Follow Momentary FIRE
1 5	GND Fire Detector (PGM4 only)	3 9	Follow Momentary MEDICAL
1 6	Twin Alert (PGM 3 only)	4 0	Follow Momentary PA
1 7	Follow Entry/Exit	4 1	Follow Momentary TAMPER
1 8	Follow Digital Output Fire Alarm	4 2	Follow Momentary DURESS
1 9	Follow Digital Output PA Alarm	4 3	Follow Momentary COMFAIL
2 0	Follow Digital Output Intruder Alarm	4 4	Follow Momentary RKPFAIL
2 1	Follow Digital Output Open/Close	4 5	Follow Momentary TESTCALL
2 2	Follow Digital Output Abort	4 6	Status LED Output
2 3	Follow Digital Output Medical Alarm	4 7	Keyfob controlled
		4 8	Follow Supervision Output

12.3 PGM Options (Function 556)


Press  .	<i>This starts the function</i>	ENTER PGM No. ---
Enter 2 digits for the PGM (01 – 12).	<i>Example shows PGM 1 This display is quickly followed by the next</i>	ENTER PGM No. 01
The current PGM options are displayed. Select any option by using the  and  keys, or use the  –  keys to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.	<i>There are 2 options</i> Option 1: Polarity On = Active High (+12V) Off = Active Low (0V) Option 2: User Testable On = Yes Off = No	PGM OPTIONS OPTION 1 OFF OPTION 2 ON

Defaults:

PGM	POLARITY	USER TESTABLE	PGM	POLARITY	USER TESTABLE
1	Off (Active Low)	On (Yes)	7	Off (Active Low)	Off (No)
2	Off (Active Low)	On (Yes)	8	Off (Active Low)	Off (No)
3	Off (Active Low)	Off (No)	9	Off (Active Low)	Off (No)
4	Off (Active Low)	Off (No)	10	Off (Active Low)	Off (No)
5	Off (Active Low)	Off (No)	11	Off (Active Low)	Off (No)
6	Off (Active Low)	Off (No)	12	Off (Active Low)	Off (No)


13. COMMUNICATIONS

13.1 Account Codes & Partitions Allocation (Function 600)

Press  .		ENTER PARTITION _
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
The current account code is displayed.	<i>Example shows account code 1234</i>	ENTER ACCNT CODE _1234
To delete the current account code, press  . You will be returned to Engineer Mode		
Enter the new account code.	<i>Example shows 65C3</i>	ENTER ACCNT CODE _65C3
Press  to accept the changes.		

DIGIT KEYPRESS	
0 – 9	0 – 9 keys
B	 followed by 2
C	 followed by 3
D	 followed by 4
E	 followed by 5
F	 followed by 6

13.2 Up/Downloading Access Code (Function 601)

Press  .		
The current code is displayed.	<i>Example shows code 3456</i>	ENTER UDL CODE _3456
Enter the 4 digits for the new code (0 – 9).	<i>Example shows 7891</i>	ENTER UDL CODE _7891
Press  to accept the changes.		

NOTE: Default is 1234.

13.3 Digital Communicator Options 1 (Function 602)

Press [6 0 2] .	<i>This starts the function</i>	DIGI COMM OPT 1 OPTION 1 OFF
The current partition options are displayed. Select any option by using the ▲ and ▼ keys, or use the [A 1] – [6] keys to select that option directly. Press [] to toggle the option ON or OFF. Press [] to accept the options.	<i>There are 6 options</i>	DIGI COMM OPT 1 OPTION 1 OFF OPTION 2 OFF OPTION 3 OFF OPTION 4 ON OPTION 5 OFF OPTION 6 ON

Nº	OPTION OFF	OPTION ON
1	Disable Telephone Line Monitoring	Enable Telephone Line Monitoring
2	Standard Handshake Filter	Wide Handshake Filter
3	Tone Dial	Pulse Dial
4	Disable AMC	Enable AMC
5	Reporting Events are Low Priority	Reporting Events are High Priority
6	Disable Send Open After Alarm	Enable Send Open After Alarm
7	Reserved for Future Use. Do Not Alter.	
8	Reserved for Future Use. Do Not Alter.	

Shaded = Default

13.4 Test Dial Time (Function 603)

Press [6 0 c 3] .		
The current test dial time is displayed.	<i>Example shows 12:43 PM</i>	ENTER TIME _1234
Enter 4 digits for the new test dial time (0000 – 2359, 24-hour format, 0000 =- disabled). NOTE: The time is automatically accepted after entering the 4th digit.	<i>Example shows 16:00 (4PM)</i>	ENTER TIME 1600

NOTE: Default is 0000 (disabled).

13.5 Test Dial Interval (Function 604)

Press  .		
The current interval is displayed.	<i>Example shows 00 (use the time set in Function 603 as an interval)</i>	ENTER INTERVAL 00
Enter 2 digits for the new interval setting (00 – 99).	<i>Example shows 12 (every 12 days at time programmed in Function 603)</i>	ENTER INTERVAL 12
Press  to accept the changes.		

NOTE: When 00 is entered as the interval, the interval between test dials is the time set in Function 603 (page 39). Therefore, if the time set in Function 603 is 00:30, there will be a test dial every 30 minutes, every day. When a number between 01 and 99 is entered as the interval, test dials will occur at the time set in Function 603, every XX days, where XX is the interval programmed here.

13.6 Telephone Number 1 Allocation (Function 605)

Press  .	<i>00 indicates no telephone number allocated</i>	ENTER TEL ALLOC 00
Enter 1 digit for the telephone number (1 – 9, 0 deletes current allocation). NOTE: A leading zero is always shown.	<i>Example shows telephone number 3 allocated as the 1st telephone number</i>	ENTER TEL ALLOC 03
Press  to accept the changes.		

NOTE: Default is 0 (no number allocated).

13.7 Telephone Number 2 Allocation (Function 606)

Press  .	<i>00 indicates no telephone number allocated</i>	ENTER TEL ALLOC 00
Enter 1 digit for the telephone number (1 – 9, 0 deletes current allocation). NOTE: A leading zero is always shown.	<i>Example shows telephone number 4 allocated as the 2nd telephone number</i>	ENTER TEL ALLOC 04
Press  to accept the changes.		

NOTE: Default is 0 (no number allocated).

13.8 Telephone Number 3 Allocation (Function 607)

Press  .	<i>00 indicates no telephone number allocated</i>	ENTER TEL ALLOC 00
Enter 1 digit for the telephone number (1 – 9, 0 deletes current allocation). NOTE: A leading zero is always shown.	<i>Example shows telephone number 1 allocated as the 3rd telephone number</i>	ENTER TEL ALLOC 01
Press  to accept the changes.		

NOTE: Default is 0 (no number allocated).

13.9 Test Dial Sequence (Function 608)

Press [↺ 6 ⌂ 0 ⌂ 8 ⌂] .	<i>The current sequence is displayed</i>	ENTER DIAL ORDER 01
Enter 1 digit to select the sequence required. NOTE: A leading zero is always shown.	<i>Example shows sequence 2</i>	ENTER DIAL ORDER 02
Press [↺] to accept the changes.		

SEQUENCE	DESCRIPTION
1	Test dial sent to telephone number 1 only
2	Test dial sent to telephone 1 and 2
3	Test dial sent to telephone 1, and if no transmission, the to telephone 2

Shaded = Default

13.10 Anti-Code Algorithm (Function 609)

Press [↺ 6 ⌂ 0 ⌂ 9 ⌂] .	<i>The current algorithm is displayed</i>	ENTER ALGORITHM 00
Enter 1 digit to select the algorithm required. NOTE: A leading zero is always shown.	<i>Example shows algorithm 3</i>	ENTER ALGORITHM 03
Press [↺] to accept the changes.		

NOTE: Pyronix Anti-Code generating software will only generate codes for algorithm 0, and therefore it is highly recommended that this setting is not altered.

13.11 Digital Communicator Options 2 (Function 610)


Press [↺ 6 ⌂ 1 ⌂ 0 ⌂] .	<i>This starts the function</i>	DIGI COMM OPT 2 OPTION 1 OFF
The current partition options are displayed. Select any option by using the [▲] and [▼] keys, or use the [A ⌂] – [B ⌂] keys to select that option directly. Press [🔒] to toggle the option ON or OFF. Press [↺] to accept the options.	<i>There are 2 options</i>	DIGI COMM OPT 2 OPTION 1 OFF OPTION 2 OFF

Nº	OPTION OFF	OPTION ON
1	Do Not Delete Pending Events on Opening After Alarm	Delete Pending Event on Opening After Alarm
2	Normal Event Dial	Fast Event Dial
3	Event ReDials = 4	Event Redials = 8
4	Send All MX485 Reporting	Follow Send Options for MX485 Reporting
5	Event Duplication = No	Event Duplication = Yes
6		
7		
8		Reserved for future use.

Shaded = Default

14. REPORTING

14.1 Telephone Number Only (Function 651)

Press  .	<i>This starts the function</i>	CHOOSE TEL No. _
Enter 1 digit to select the telephone number to be changed.	<i>Example shows telephone number 1 This display is quickly followed by the next</i>	CHOOSE TEL No. _1
The current telephone number is displayed.	<i>Example shows no telephone number entered.</i>	
To delete the current telephone number, press  .		
You will be returned to Engineer Mode.		
Enter up to 32 digits for the new telephone number.	<i>Example shows 555D2352634 where D = 3 second pause</i>	555B2352634_
Press  to accept the changes.		

KEY(S)	DISPLAY	MEANING
0 – 9	0 – 9	0 – 9
	D	3 second pause
 	B	*
 	C	#

14.2 Telephone Format Only (Function 652)

Press  .	<i>This starts the function</i>	CHOOSE TEL No. —
Enter 1 digit to select the telephone number to be changed.	<i>Example shows telephone number 1 This display is quickly followed by the next</i>	CHOOSE TEL No. _1
The current report format setting is displayed.	<i>Example shows 0 (Contact ID)</i>	ENTER FORMAT No. 00
Enter 1 digit for the reporting format (1 – 4). NOTE: A leading zero is always shown.	<i>Example shows 1 (BSIA Fast Format)</i>	ENTER FORMAT No. 01
Press  to accept the changes.		

Nº	TYPE
0	Contact ID Format
1	BSIA Fast Format
2	Pyronix Format
3	Pager Format
4	Voice Format

Shaded = Default

14.3 BSIA Format Channel Map (Function 655)

Press  .	<i>The current map is displayed</i>	ENTER MAP INFO — 12345678
Enter 8 digits (1 – 8). NOTE: All 8 digits MUST be different. NOTE: The map is automatically accepted after entering the 8th digit.	<i>Example shows 1 (BSIA Fast Format)</i>	ENTER MAP INFO 87654321

DIGITS ENTERED	MEANING
1	Fire
2	PA
3	Intruder
4	Open/Close
5	Abort
6	Medical
7	Confirmed
8	Omit

15. SEND OPTIONS

15.1 Disarmed Mode Events Send Options (Function 700)

Press  .	<i>This starts the function</i>	ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
The current options are displayed. Select any option by using the  and  keys, or use the  –  keys to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.	<i>There are 8 options</i>	DISARMED SIGNALS OPTION 1 ON OPTION 2 ON OPTION 3 ON OPTION 4 ON OPTION 5 ON OPTION 6 ON OPTION 7 ON OPTION 8 ON

Nº	OPTION OFF	OPTION ON
1	Alarms are Not Sent	Alarms are Sent
2	PA Alarms are Not Sent	PA Alarms are Sent
3	Fire Alarms are Not Sent	Fire Alarms are Sent
4	Maintenance Events are Not Sent	Maintenance Events are Sent
5	Open/Close Events are Not Sent	Open/Close Events are Sent
6	Medical Alarms are Not Sent	Medical Alarms are Sent
7	Confirmed Alarms are Not Sent	Confirmed Alarms are Sent
8*	Omit (Bypass) Events are Not Sent	Omits (Bypass) Events are Sent

Shaded = Default

***NOTE: Italy – Omit (Bypass) Events MUST be reported for all Arm Modes to comply with CEI79.**

Belgium – Omit (Bypass) Events MUST be reported for all Arm Modes to comply with T014.

15.2 Arm Mode A Events Send Options (Function 701)**15.3 Arm Mode B Events Send Options (Function 702)****15.4 Arm Mode C Events Send Options (Function 703)****15.5 Arm Mode D Events Send Options (Function 704)**

Programming for Arm Mode A is shown.

Press 	<i>This starts the function</i>	ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
The current options are displayed. Select any option by using the  and  keys, or use the  –  keys to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.	<i>There are 8 options</i>	ARM A SIGNALS OPTION 1 ON OPTION 2 ON OPTION 3 ON OPTION 4 ON OPTION 5 ON OPTION 6 ON OPTION 7 ON OPTION 8 ON

Nº	OPTION OFF	OPTION ON
1	Alarms are Not Sent	Alarms are Sent
2	PA Alarms are Not Sent	PA Alarms are Sent
3	Fire Alarms are Not Sent	Fire Alarms are Sent
4	Maintenance Events are Not Sent	Maintenance Events are Sent
5	Open/Close Events are Not Sent	Open/Close Events are Sent
6	Medical Alarms are Not Sent	Medical Alarms are Sent
7	Confirmed Alarms are Not Sent	Confirmed Alarms are Sent
8*	Omit (Bypass) Events are Not Sent	Omits (Bypass) Events are Sent

Shaded = Default

***NOTE: Italy – Omit (Bypass) Events MUST be reported for all Arm Modes to comply with CEI79.**

Belgium – Omit (Bypass) Events MUST be reported for all Arm Modes to comply with T014.

15.6 Restoral Events Send Options (Function 705)

Press  7 0 5.	<i>This starts the function</i>	ENTER PARTITION _
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
The current options are displayed. Select any option by using the  and  keys, or use the  –  keys to select that option directly. Press  to toggle the option ON or OFF. Press  to accept the options.	<i>There are 8 options</i>	DIGI RESTORALS OPTION 1 ON OPTION 2 ON OPTION 3 ON OPTION 4 ON OPTION 5 ON OPTION 6 ON OPTION 7 ON OPTION 8 ON

Nº	OPTION OFF	OPTION ON
1	Alarms are Not Sent	Alarms are Sent
2	PA Alarms are Not Sent	PA Alarms are Sent
3	Fire Alarms are Not Sent	Fire Alarms are Sent
4	Maintenance Events are Not Sent	Maintenance Events are Sent
5	Open/Close Events are Not Sent	Open/Close Events are Sent
6	Medical Alarms are Not Sent	Medical Alarms are Sent
7	Confirmed Alarms are Not Sent	Confirmed Alarms are Sent
8*	Omit (Bypass) Events are Not Sent	Omits (Bypass) Events are Sent

Shaded = Default

***NOTE: Italy – Omit (Bypass) Events MUST be reported for all Arm Modes to comply with CEI79.**

Belgium – Omit (Bypass) Events MUST be reported for all Arm Modes to comply with T014.

15.7 Allocating Telephone Numbers to Alarm Types (Function 706)

Press  .	<i>This starts the function</i>	ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
Enter the alarm type (1 – 8)	<i>Valid alarm types are: 1 = Alarm 2 = PA 3 = Fire 4 = Maintenance 5 = Open/Close 6 = Medical Alarm 7 = Confirmed 8 = Omit This display is quickly followed by the next</i>	ENTER ALARM TYPE —
Enter 1 digit to select the telephone number to be used for Tel 1 (1 – 9). NOTE: A leading zero is always shown. Press  to accept.	<i>Example shows telephone number 1</i>	ENTER TEL ALLOC 01
Enter 1 digit to select the telephone number to be used for Tel 2 (1 – 9). NOTE: A leading zero is always shown. Press  to accept.	<i>Example shows telephone number 2</i>	ENTER TEL ALLOC 02
Enter 1 digit to select the telephone number to be used for Tel 3 (1 – 9). NOTE: A leading zero is always shown. Press  to accept.	<i>Example shows telephone number 3</i>	ENTER TEL ALLOC 03
Enter 1 digit to select Tel 1 & Tel 2 reporting sequence (1 – 3). Press  to accept the changes.	<i>Valid sequences are: 1 = Only send to Tel 1 2 = Send to Tel 1 & Tel 2 3 = Tel 2 only if Tel 1 busy</i>	ENTER SEQUENCE 02

NOTE: Default is Telephone Number 1 for telephone 1, Telephone Number 2 for telephone 2, and 0 for telephone 3, for all alarm types.

15.8 MX-VOICE Module Support (Function 707)

Press  7  0  .	<i>This starts the function</i>	ENTER PARTITION _
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
Enter the alarm type (1 – 8)	<i>Valid alarm types are: 1 = Alarm 2 = PA 3 = Fire 4 = Maintenance 5 = Open/Close 6 = Medical Alarm 7 = Confirmed 8 = Omit This display is quickly followed by the next</i>	ENTER ALARM TYPE _
The current voice message number is displayed.	<i>Example shows voice message 2</i>	ASSIGN VOICE MSG 02
Enter 1 digit to assign the voice message (1 – 8).	<i>Example shows voice message 1</i>	ASSIGN VOICE MSG 01
Press  to accept the changes.		

NOTE: By default all alarm types activate voice message 1, except Close events, which activate voice message 2.

15.9 Number of Voice Dials (Function 709)

Press  7  0  .	<i>This starts the function</i>	ENTER VOICE QTY 01
Enter 1 digit to assign the new number of voice dials (1 – 8). NOTE: A leading zero is always shown.	<i>Example shows 3 voice dials</i>	ENTER VOICE QTY 03
Press  to accept the changes.		

NOTE: Default is 1.

16. MAINTENANCE

16.1 Viewing Event Log Memory (Function 113)

Press  .	<i>The second to last event is displayed. This is because the last event is usually entering Engineer Mode, and this is not really relevant to most diagnostic exercises</i>	00:12 SUN 01 JAN >DISARMED
Press the  key to view more recent events.		00:13 SUN 01 JAN >ENGINEER START
Press the  key to view older events.	<i>Example shows a user code was entered after an alarm</i>	00:11 SUN 01 JAN >UC POST ALARM
To view more information about an event, press the  .	<i>Example shows that Sandra (user 01) entered the user code</i>	SANDRA >01
NOTE: Some events do not have additional information, and you will see a blank screen as a result.	<i>Example shows an event with no additional information</i>	>
To return to the event press the  .		00:11 SUN 01 JAN >UC POST ALARM
Press  to exit the log.		

16.1.1 Event Log Interpretation Table

DESCRIPTION	 / 		MAIN ENTRY	ADDITIONAL DATA
Beginning of the log	DISPLAY LOG ▼			
End of the log	DISPLAY LOG ▲			
ALARMS & TAMPERS				
Entry time expired.	TIME & DATE			ZONE NAME
The number refers to the zone	►ENTRY / EXIT			►01-32
Burglary on zone, number signifies zone	TIME AND DATE ►ALARM			ZONE NAME ►01-32
Tamper on zone, number signifies zone	TIME AND DATE ►ZONE TAMPER			ZONE NAME ►01-32
PA zone activated, number signifies zone	TIME AND DATE ►PERSONAL ATK			►01-32
Fire zone activated, number signifies zone	TIME AND DATE ►FIRE ALARM			►01-32
2-wire Fire detector input activated (PGM4)	TIME AND DATE ►FIRE ALARM			►99
Medical zone activated, number signifies zone	TIME AND DATE ►MEDICAL ALARM			►01-32
PA alarm activated from a keypad	TIME AND DATE ►PERSONAL ATTACK			►00
Fire alarm activated from a keypad	TIME AND DATE ►FIRE ALARM			►00
Medical alarm activated from a keypad	TIME AND DATE ►MEDICAL ALARM			►00
Telephone line fail alarm	TIME AND DATE ►TEL LINE ALARM	►		
Global tamper loop broken	TIME AND DATE ►TAMPER			►01
Bell tamper loop broken	TIME AND DATE ►TAMPER			►02
Plug on zone expander board not present	TIME AND DATE ►TAMPER			►03
2-wire Fire detector input tamper (PGM4)	TIME AND DATE ►TAMPER			►05
Remote device missing caused tamper	TIME AND DATE ►TAMPER			►06
Keypress tamper – 16 wrong keypress in armed mode	TIME AND DATE ►TAMPER			►08
Remote device case tamper	TIME AND DATE ►TAMPER			►09
Remote device front tamper activation, 01 – 82 = Type/ID	TIME AND DATE ►DEVICE TAMPER		DEVICE 01-82	►01-82 01

DESCRIPTION			MAIN ENTRY	ADDITIONAL DATA
RESTORALS				
Zone restore, number signifies zone	TIME AND DATE ►ALARM RESTORE		ZONE NAME ►01-32	
Tamper restore, number signifies zone	TIME AND DATE ►ZONE RESTORE		ZONE NAME ►01-32	
PA zone restore, number signifies zone	TIME AND DATE ►PA RESTORE		►01-32	
Fire zone restore, number signifies zone	TIME AND DATE ►FIRE RESTORE		►01-32	
Medical zone restore, number signifies zone	TIME AND DATE ►MEDICAL RESTORE		►01-32	
Remote device front tamper restore, 01 – 84 = Type/ID	TIME AND DATE ►DEVICE RESTORE		►01-82 01	
User code after alarm, number signifies user (enter FTA mode)	TIME AND DATE ►UC POST ALARM		USER NAME ►01-32	
Bell time expired	TIME AND DATE ►BELL TIME END		►	
Panel powered up	00:00 MON 01 JAN ►POWER ON		►	
OPEN / CLOSE (DISARM / ARM)				
Armed in mode A by user, number signifies code used	TIME AND DATE ►ARMED		USER NAME ►01-32 A	
Armed in mode B by user, number signifies code used	TIME AND DATE ►ARMED		USER NAME ►01-32 B	
Armed in mode C by user, number signifies code used	TIME AND DATE ►ARMED		USER NAME ►01-32 C	
Armed in mode D by user, number signifies code used	TIME AND DATE ►ARMED		USER NAME ►01-32 D	
Armed in mode A-D by keyswitch zone	TIME AND DATE ►ARMED		KEY ►00 A-D	
Armed in mode A-D by engineer (from Engineer Mode or from a PC)	TIME AND DATE ►ARMED		ENGINEER ►99 A-D	
Armed due inactivity / auto arm timer	TIME AND DATE ►TIMED ARM		►	
Disarmed (or reset alarm) by user, number signifies code used	TIME AND DATE ►DISARMED		USER NAME ►01-32	
Disarmed (or reset alarm) by keyswitch zone	TIME AND DATE ►DISARMED		KEY ►00	
Disarmed by engineer (from Engineer Mode or from a PC)	TIME AND DATE ►DISARMED		ENGINEER ►99	
Disarmed due to dependency on other partitions	TIME AND DATE ►DISARM DEPEND		►	
Zone omitted, number signifies zone	TIME AND DATE ► OMIT ZONE		ZONE NAME ►01-32	

DESCRIPTION	MAIN ENTRY		ADDITIONAL DATA
	▲ / ▼	▶	
SYSTEM FAULTS			
Bell fuse fail	TIME AND DATE ►BELL FUSE FAIL	▶	
Auxiliary fuse fail	TIME AND DATE ►AUX FUSE FAIL	▶	
Battery missing / Battery fuse fail (DC voltage missing on terminals "+BAT-")	TIME AND DATE ►BATTERY MISSING	▶	
Battery low voltage (DC voltage on terminals +BAT- is less than 10,7V)	TIME AND DATE ►BATTERY LOW	▶	
Mains fail (AC voltage missing on terminals "17V~")	TIME AND DATE ►MAINS FAIL	▶	
Telephone line fail	TIME AND DATE ►TELEPHONE FAIL	▶	
Battery fault on Wireless detector(s)	TIME AND DATE ►ZONE BAT FAULT	ZONE NAME ►01-32	
Battery fault on keyfob(s)	TIME AND DATE ►KEY FOB BAT FLT	USER NAME ►01-32	
Jamming fault detected on wireless expander	TIME AND DATE ►JAMMING FAULT	EXPANDER ►01-02	
Detector signal low	TIME AND DATE ►LOW SIGNAL	ZONE NAME ►01-32	
Detector signal has gone missing	TIME AND DATE ►SIGNAL LOST	ZONE NAME ►01-32	
Remote device has gone missing on bus	TIME AND DATE ►DEVICE FAIL	▶	
Failed to report to central station	TIME AND DATE ►FAIL TO REPORT	▶	
Bell fuse fail restore	TIME AND DATE ►RESTORE	►BELL FUSE FAIL	
Auxiliary fuse fail restore	TIME AND DATE ►RESTORE	►AUX FUSE FAIL	
Battery missing / Battery fuse fail restore	TIME AND DATE ►RESTORE	►BATTERY MISSING	
Battery low voltage restore	TIME AND DATE ►RESTORE	►BATTERY LOW	
Mains fail restore	TIME AND DATE ►RESTORE	►MAINS FAIL	
Telephone line fail restore	TIME AND DATE ►RESTORE	►TELEPHONE FAIL	
Battery fault on wireless detector(s) restore	TIME AND DATE ►ZONE BAT OK	ZONE NAME ►01-32	
Battery fault on keyfob(s) restore	TIME AND DATE ►KEY FOB BAT OK	USER NAME ►01-32	

DESCRIPTION	▲ / ▼ MAIN ENTRY	► ADDITIONAL DATA
Jamming fault restore	TIME AND DATE ►JAMMING CLEAR	EXPANDER ►01-02
Detector signal restore	TIME AND DATE ►SIGNAL OK	ZONE NAME ►01-32
Detector signal restore	TIME AND DATE ►SIGNAL FOUND	ZONE NAME ►01-32
Remote device has been found on bus (restore)	TIME AND DATE ►RESTORE	►DEVICE FAIL
Successful transmission to central station (restore)	TIME AND DATE ►RESTORE	►FAIL TO REPORT
SYSTEM EVENTS		
Engineer mode exited	TIME AND DATE ►ENGINEER END	►
Engineer mode entered	TIME AND DATE ►ENGINEER START	►
Walk test mode entered	TIME AND DATE ►WALK TEST ENTER	►
Walk test mode exited	TIME AND DATE ►WALK TEST EXIT	►
NVM reset to factory defaults	TIME AND DATE ►NVM RESET	►
Time and date changed by user, number signifies code used	TIME AND DATE ►TIME+DATE	USER NAME ►01-32
Time and date changed by engineer	TIME AND DATE ►TIME+DATE	USER NAME ►01-32
Remote device lost on bus, number refers to type/ID	TIME AND DATE ►DEVICE LOST	►01-82
Remote device found on bus, number refers to type/ID	TIME AND DATE ►DEVICE FOUND	►01-82
UP/DOWNLOADING EVENTS		
Panel answered the telephone	TIME AND DATE ►PANEL ANS TEL.	►
Panel hung up the telephone line	TIME AND DATE ►PANEL HUNG TEL.	►
Full data upload to panel	TIME AND DATE ►FULL UPLOAD	►
Full data download from panel	TIME AND DATE ►FULL DOWNLOAD	►
Partial data upload to panel	TIME AND DATE ►PARTIAL UPLOAD	►
Upload data to panel complete	TIME AND DATE ►UPLOAD COMPLETE	►
Download data from panel complete	TIME AND DATE ►DOWNLD COMPLETE	►

DESCRIPTION	▲ / ▼ ▶ MAIN ENTRY	ADDITIONAL DATA
UDL session denied (up/download code incorrect)	TIME AND DATE ►BAD UDL CODE	▶
UDL session start-up (up/download code accepted)	TIME AND DATE ►UDL CODE OK	▶
Time and date changed by PC	TIME AND DATE ►TIME+DATE	▶
Enter command to initiate local UDL session (local connection expected)	TIME AND DATE ►LC EXPECTED	▶
Arm/Disarm command received from a PC	TIME AND DATE ►PC ARM/DISARM	▶

16.2 Engineer Code NVM Reset (Function 751)

Press 7 5 A 1 .

This starts the function

NUM RESET
SYSTEM BUSY

An acceptance or low error tone indicates whether the function succeeded or failed. This usually takes a number of seconds to complete.

On completion of the function (pass or failure) you will be returned to Engineer Mode.

16.3 Programmable Outputs Test (Function 752)

Press 7 5 B 2 .

This starts the function

PGM TO TEST ?
--

Enter the PGM output you want to test as a 2-digit number (01 – 12)

Example shows PGM 1

PGM TO TEST ?
01

Press to toggle the PGM output.

Repeat for further outputs as needed.

Press to exit the function.

The original state of the outputs will be restored

16.4 Walk Test (Function 753)

Press 7 5 C 3 .

This starts the function

PRESS A, B, C OR D

Enter 1 digit for the Arm Mode (1 = A ... 4 = D)

Example shows Arm Mode A selected

WALK TEST
ARM MODE A

Open / close the zones you wish to test.

Example shows Zone 1

WALK TEST
ZONE 1

Repeat for other zones as needed.

Press to exit the function.

16.5 Scan for Devices on the Bus (Function 754)

Press 7 5 D 4 .

This starts the function

SCAN FOR DEVICES
01

A progress counter appears.

It counts up in tens (1-8) and units (1-4 & 1-2) until 82 is reached.

At the end of the scan all devices are reset.

NOTE: When this function is run from the Engineer Menu, some of the messages may be difference from those shown here.

Example shows Arm Mode A selected

ENGINEER MODE
01

ENGINEERS MODE
82

You are automatically returned to Engineer Mode.

16.6 Local Up/Downloading – RS232 (Function 755)

Press 7 5 5 .

This starts the function

RS232 UDL ENABLE
SYSTEM BUSY

The display will remain until either completed your UDL session or no connection was made within 30 seconds.


16.7 Battery Charger Test (Function 756)

Press  7  5  6  .	<i>This starts the function</i>	BATT CHARGE TEST
The test starts after approximately 2 seconds. A battery MUST be connected.		
The charger circuit is switched OFF for approximately 20 seconds.	<i>A progress bar is displayed</i>	BATT CHARGE TEST >
The charger circuit is switched ON for a minimum of approximately 10 seconds.	<i>A progress bar is displayed</i>	BATT CHARGE TEST >>>>>>>
When testing is complete a test result is displayed.		BATT CHARGE TEST PASS BATT CHARGE TEST FAIL
Press  to exit the function.		

NOTE: A **PASS** message always indicates a test pass. A **FAIL** result however may be displayed under certain conditions even though the battery charging circuit is working correctly. This is due partly because of the length of the test. A much longer test would always correctly diagnose a passed battery charging circuit, although the test would take far too long for practical purposes.

If you receive a FAIL message then use the following steps to confirm it:

- Configure a multimeter for current measurement (>600mA scale)
- Attach the multimeter in-line with the BAT+ terminal (see diagram below)
- Re-run this function
- Check that the current starts at 0A and turns ON after approximately 20 seconds, for a minimum of 5 seconds. This indicates a test **pass**. If the current measurement remains at 0A all of the time, then this indicates a test failure.



16.8 Panel Software Version Number (Function 757)

The following procedure shows who to identify the software version number of the panel.

Press  7  5  7 

This starts the function

VERSION
V4.00

- This display will display the version number of the panel.

Press  to exit the function

17. DD243

17.1 DD243 Options 1 (Function 800)

Press 4 8 0 0 .	<i>This starts the function</i>	DD243 OPT 1 OPTION 1 OFF
The current options are displayed. Select any option by using the ▲ and ▼ keys, or use the A 1 8 – 8 keys to select that option directly. Press LOCK to toggle the option ON or OFF. Press 4 to accept the options.	<i>There are 7 options</i>	DD243 OPT 1 OPTION 1 OFF OPTION 2 OFF OPTION 3 ON OPTION 4 ON OPTION 5 ON OPTION 6 ON OPTION 7 OFF

Nº	OPTION OFF	OPTION ON
1	Disable DD243 Options 2 – 8	Enable DD243 Options 2 – 8
2	Open Set Zone Does Not Stop Confirmation	Open Set Zone Stops Confirmation
3	Open Entry Zone Does Not Stop Confirmation	Open Entry Zone Stops Confirmation
4	Auto Omit Open Zones at End of Bell Time	Auto Omit Open Zones at End of Confirmation Time
5	Lost Zone Expander Does Not Cause Confirmed Alarm	Lost Zone Expander Causes Confirmed Alarm
6	Fire, PA & Medical Keys are Enabled	Fire, PA & Medical Keys are Disabled
7	Entry Timer End Re-enables Confirmation	Entry Timer End Does Not Re-enable Confirmation
8	Reserved for Future Use. Do Not Alter.	

Shaded = Default

17.2 DD243 Zone Map (Function 802)

Press 4 8 0 8 2 .	<i>This starts the function</i>	ENTER ZONE No. --
Enter a 2-digit zone number (01 – 32).	<i>Example shows zone 1 This display is quickly followed by the next</i>	ENTER ZONE No. 01
The current zone map number is displayed.	<i>Example shows zone map 01</i>	DD243 ZONE MAP 01
Enter a new 2-digit zone map number (01 – 99).	<i>Example shows zone map 03</i>	DD243 ZONE MAP 03
Press 4 to accept the changes.		

17.3 DD243 Partition Confirmation Times (Function 804)

Press  .	<i>This starts the function</i>	ENTER PARTITION —
Enter 1 digit for the partition (1 – 4).	<i>Example shows Partition 1 This display is quickly followed by the next</i>	ENTER PARTITION _1
The current confirmation time is displayed.	<i>Example shows 30 minutes</i>	CONFIRM TIME ? 30
Enter the new confirmation time as a 2-digit number (00 – 99).	<i>Example shows 20 minutes</i>	CONFIRM TIME ? 20
Press  to accept the changes.		

NOTE: Default is 30 minutes for all partitions.

18. WIRELESS

18.1 Program Key fob (Function 900)

This function allows you to select which actions you would like the key fob to operate.

Press  9 0 0	This starts the function	ENTER PARTITION -
Enter 1 digit for the partition number (1-4)	<i>Example shows partition 1</i> <i>This display is quickly followed by the next</i>	ENTER PARTITION -1
Choose an action for button 1	<i>The default action will be shown</i>	BUTTON 1 12
Choose an action for button 2	<i>The default action will be shown</i>	BUTTON 2 05
Choose an action for button 3	<i>The default action will be shown</i>	BUTTON 3 11
Choose an action for button 4	<i>The default action will be shown</i>	BUTTON 4 11
Choose an action for buttons 1 and 2	<i>The default action will be shown</i> <i>Simultaneous press of buttons 1 and 2</i>	BUTTON 1+2 11
Choose an action for buttons 3 and 4	<i>The default action will be shown</i> <i>Simultaneous press of buttons 3 and 4</i>	BUTTON 3+4 11
Press  to accept, You will be returned to engineer's mode.		

Defaults:

Button	Action	Button	Action
1	12	4	11
2	05	1+2	11
3	11	3+4	11

18.2 Key Fob Actions

Number	Action	Number	Action
01	Arm A	09	Medical Alarm
02	Arm B	10	Personal Attack
03	Arm C	11	Not Used
04	Arm D	12	Quick Arm A
05	Disarm	13	Quick Arm B
06	RKP Controlled	14	Quick Arm C
07	Key fob Controlled	15	Quick Arm D
08	Fire Alarm		

18.3 Supervision Time (Function 901)

The supervision time ranges from 00 (off), to 99 (99 hours) and is used to check the radio detectors/transmitters on the system.

Press [] 9 [] 0 [^ 1 []	<i>This starts the function</i>	SUPERVISION TIME ---
Enter the supervision time (default 2 hours) Press [] to accept.		SUPERVISION TIME ---

An output type 'Follow Supervision Time' is also available. See Function 555 for outputs.

19. CONTACT ID EVENT CODES

Q	EEE	English Equivalent	Matrix System Events	PP	NNN
<u>Group 1: INTRUDER ALARMS</u>					
1 or 3	130	Burglary	Immediate or Access Zone – Alarm / Restoral	01-04	001-032
1 or 3	133	24 Hour	24 Hour Zone – Alarm / Restoral	01-04	001-032
1 or 3	134	Entry / Exit	Entry / Exit Zone – Alarm / Restoral	01-04	001-032
1 or 3	137	Tamper	Global Tamper Loop (GT Input) – Alarm / Restoral	01-04	001
1 or 3	137	Tamper	Keypress Tamper – Alarm / Restoral	01-04	003
1 or 3	143	Expansion Module Fault	Remote Device Missing / Restoral (MX-IX16)	01-04	002
1 or 3	143	Expansion Module Fault	Remote Device Missing / Restoral (MX-RIX16 – ID1)	01-04	061
1 or 3	143	Expansion Module Fault	Remote Device Missing / Restoral (MX-RIX16 – ID2)	01-04	062
1 or 3	143	Expansion Module Fault	Remote Device Missing / Restoral (MX-ROX8)	01-04	041
1 or 3	143	Expansion Module Fault	Remote Device Missing / Restoral (MX-LCD)	01-04	001-004
1 or 3	143	Expansion Module Fault	Remote Device Missing / Restoral (MX-LCD ICON)	01-04	011-014
1 or 3	143	Expansion Module Fault	Remote Device Missing / Restoral (MX-PROX)	01-04	021-024
1 or 3	144	Sensor Tamper	EOL Zone – Tamper / Restoral	01-04	001-032
1 or 3	146	Silent Burglary	Immediate or Access Zone – Bell Delay Alarm / Restoral	01-04	001-032
1 or 3	321	Bell Tamper	Bell Tamper Loop (BT Input) – Alarm / Restoral	01-04	000
1 or 3	373	Tamper	2 Wire Fire Detector Loop (on PGM4) – Tamper / Restoral	01-04	099
1 or 3	383	Sensor Tamper	Tamper Zone – Alarm / Restoral (Internal alarm only / no bell activation)	01-04	001-032
<u>Group 2: PERSONAL ATTACK ALARMS</u>					
1	121	Duress	Arm or Disarm by Duress User Code	01-04	001-032
1 or 3	122	Silent Panic	Silent PA Alarm / Restoral from Keypad	01-04	000
1 or 3	122	Silent Panic	Personal Attack Zone – Silent Alarm / Restoral	01-04	001-032
1 or 3	123	Audible Panic	Audible PA Alarm / Restoral from Keypad	01-04	000
1 or 3	123	Audible Panic	Personal Attack Zone – Audible Alarm / Restoral	01-04	001-032
<u>Group 3: FIRE ALARMS</u>					
1 or 3	110	Fire	Fire Alarm / Restoral from Keypad	01-04	000
1 or 3	110	Fire	2 Wire Fire Detector Loop (on PGM4) – Alarm / Restoral	01-04	099
1 or 3	110	Fire	Fire Zone – Alarm / Restoral	01-04	001-032
<u>Group 4: MAINTENANCE</u>					
1 or 3	301	AC Power	AC Mains – Fail / Restoral	01	000
1 or 3	302	Low Battery	Battery Missing or Low Battery – Fail / Restoral	01	000
1	305	System Reset	Panel Powered Up	01	000
1 or 3	344	Jam Detect	RF Expander experiencing Jamming	01-04	000
1 or 3	381	Supervision Loss	Detector stopped checking in	01-04	016-032
1 or 3	384	RF Low Battery	Low battery in RF detector	01-04	016-032
1	412	Successful UDL	Data was successfully uploaded from / downloaded from panel	01	000
1 or 3	607	Walk Test Mode	Walk Test Mode – Entered / Left	01-04	000
1 or 3	623	Event Log 90% Full	Event Log 90% of Capacity	01	000
1	627	Program Mode Entry	Engineer Mode Entered	01	099
1	628	Program Mode Exit	Engineer Mode Left	01	099
<u>Group 5: OPEN/CLOSE</u>					
1 or 3	401	User	Open (Disarm) / Close (Arm) by User Code	01-04	001-032
1 or 3	401	User	Open (Disarm) / Close (Arm) from Engineer Mode or PC	01-04	099
1	403	Automatic	Open (Disarm) by Partition Dependency	01-04	000

Q	EEE	English Equivalent	Matrix System Events	PP	NNN
3	403	Automatic	Close (Arm) by Inactivity of Auto Arm Timers	01-04	000
3	403	Automatic	Close (Arm) On Power Up	01-04	099
1 or 3	409	Keypad	Open (Disarm) / Close (Arm) by Keypad Zone	01-04	000

Group 6: MEDICAL ALARMS

1 or 3	100	Personal Emergency	Medical Alarm / Restoral from Keypad	01-04	000
1 or 3	100	Personal Emergency	Medical Zone – Alarm / Restoral	01-04	001-032

Group 7: CONFIRMED ALARMS

1 or 3	139	Confirmed Alarm	Alarm code send after activation of any 2 zones within one arm period	01-04	000
--------	-----	-----------------	---	-------	-----

Group 8: OMIT (BYPASS)

1	570	Zone Bypass	Normal Zone Omitted (Bypassed) On Arm or Auto Rearm	01-04	001-032
1	571	Zone Bypass	Fire Zone Bypasses on Arm	01-04	001-032
1	572	24 Hour Bypass	24 Hour Zone Omitted (Bypassed) On Arm or Auto Rearm	01-04	001-032

ABORT

1	406	Open After Alarm	Abort / Cancel with User Code after Alarm	01-04	000
---	-----	------------------	---	-------	-----

TEST DIALS

1	602	Periodic	Periodic Test Call	01	000
1 or 3	250	Keybox & Patrol	Keybox Zone – Opened / Closed	01-04	001-032
1	406	Open After Alarm	Abort / Cancel with User Code after Alarm	01-04	000

KEYBOX & PATROL

1 or 3	250	Keybox & Patrol	Keybox Zone – Open (Disarm) / Close (Arm)	01-04	001-016
--------	-----	-----------------	---	-------	---------

Message string of CID: [AAAA] [CC] [Q] [EEE] [PP] [NNN] [m]

[AAAA] Account Number

[CC] Reporting Format (18 for CID)

[Q] Event Qualifier: 1 = New Event or Opening, 3 = New Restore or Closing

[EEE] Digital Event Code

[PP] Partition Number

[NNN] Zone Number / User Number / Component Qualifier












[m] Checksum

20. ENGINEER QUICK REFERENCE




20.1 Entering / Exiting Engineer Mode

Enter Engineer Mode	 (default engineer code - 9999). Press  .
Exit Engineer Mode	Press  then  . If any tampers are active, then these will be displayed on the keypad. Press  then  to exit engineer's mode.






20.2 Programming Functions

	Change Engineer Code	page 9
	System Options 1	page 10
	System Options 2	page 11
	System Options 3	page 12
	Global Zone Options	page 13
	Edit Zone Names	page 13
	Zone Type – Arm Mode A	page 15
	Zone Type – Arm Mode B	page 15
	Zone Type – Arm Mode C	page 15
	Zone Type – Arm Mode D	page 15
	Zone Attributes – Arm Mode A	page 16
	Zone Attributes – Arm Mode B	page 16
	Zone Attributes – Arm Mode C	page 16
	Zone Attributes – Arm Mode D	page 16
	Zone Partition	page 17
	Copy Arm Mode A to B, C & D	page 17
	User Code Partition Allocation & Attributes	page 18
	User Code Attributes	page 18
	Maximum Code Uses	page 19
	ICON Keypad Partition Allocation	page 20
	ICON Keypad Private Option	page 20
	LCD Keypad Partition Allocation	page 21
	LCD Keypad Private Option	page 21
	Edit Label Messages	page 22
	Disarmed Message Allocation	page 23
	Armed Message Allocation	page 23
	Set Contrast	page 23
	Proximity Reader Partition Allocation	page 23
	Proximity Reader Private Option	page 24
	Change Default Language	page 24
	System Faults Warning Partition Allocation	page 25

C 3 8 A 1	Bell/Global Tamper Faults Warning Partition Allocation	page 25
D 4 0 0	Partition Options 1	page 26
D 4 0 A 1	Partition Options 2	page 27
D 4 5 0	Exit Terminator Type for Arm A	page 28
D 4 5 A 1	Exit Terminator Type for Arm B	page 28
D 4 5 B 2	Exit Terminator Type for Arm C	page 28
D 4 5 C 3	Exit Terminator Type for Arm D	page 28
D 4 5 D 4	Home and Away Allocation	page 29
D 4 5 5	Partition Dependency Options	page 30
D 4 5 6	Keyswitch Zone Arm Mode Allocation	page 31
D 4 5 7	Number of Rearms	page 31
5 0 0	Bell Timer	page 32
5 0 A 1	Bell Delay Timer	page 32
5 0 B 2	Entry Timer	page 32
5 0 C 3	Exit Timer	page 33
5 0 D 4	Final Exit Delay Timer	page 33
5 0 5	Auto Arm Commencing Time of Every Day	page 33
5 0 6	Inactivity Auto-Arm Timer	page 34
5 0 7	AC Fail Warning & Report Delay Timer	page 34
5 0 8	Telephone Line Fail Warning & Report Delay Timer	page 34
5 0 9	Seconds In Last Minute Of The Day Timer	page 34
5 5 A 1	Zone to Follow in Partition	page 35
5 5 5	PGM Output Types	page 35
5 5 6	PGM Options	page 37
6 0 0	Account Codes Programming	page 38
6 0 A 1	Upload/Download Code Programming	page 38
6 0 B 2	Telephone Line Options 1	page 39
6 0 C 3	Test Dial Time	page 39
6 0 D 4	Test Dial Interval	page 40
6 0 5	Test Dial Telephone 1 Allocation	page 40
6 0 6	Test Dial Telephone 2 Allocation	page 40
6 0 7	Test Dial Telephone 3 Allocation	page 40
6 0 8	Test Dial Sequence	page 41
6 0 9	Anti-Code Algorithm	page 41
6 A 1 0	Telephone Line Options 2	page 41
6 5 A 1	Telephone Number Programming	page 42
6 5 B 2	Telephone Format Allocation	page 42
6 5 5	BSIA Format Channel Map	page 43
7 0 0	Disarmed Mode Send Options	page 44
7 0 A 1	Arm Mode A Send Options	page 45

	Arm Mode B Send Options	page 45
	Arm Mode C Send Options	page 45
	Arm Mode D Send Options	page 45
	Restoral Events Send Options	page 46
	Allocating Telephone Numbers to Event Groups	page 47
	Allocating Voice Messages to Event Groups	page 48
	Number of Voice Message Dials	page 48
	DD243 Options	page 58
	DD243 Zone Map	page 58
	DD243 Partition Confirmation Times	page 58
	Program Keyfob	page 60
	Radio Supervision Time	Page 61

20.3 Engineer Functions

	Display Event Log	page 49
	NVM Reset to Factory Default	page 55
	PGM Outputs Test	page 55
	Walk Test	page 55
	Scan for Device on the Bus	page 55
	Initiate Local UDL Session	page 55
	Battery Charger Test	page 56
	Panel Software Version Number	page 57



Pyronix Limited
Pyronix House
Braithwell Way
Hellaby, Rotherham
S66 8QY, UK

Customer Support line (UK only): +44(0)845 6434 999 (local rate)

Or telephone: +44(0)1709 535225

Hours of business: 8:00 AM – 6:30 PM, Monday to Friday

Email: customer.support@pyronix.com

Website: www.pyronix.com